

B-20

B-20

B-20

B-21

Hollow Out

Hollow Out

Wing Rest

Wing Placement

Remove After Wing Placement

1/8" Plywood

1/8" Plywood

1/8" Plywood