



**THE
BAYNE COMPANY**
Makers of the Original Star-Lock & ProTop

Installation Recommendations

STAR-LOCK

- Use 3-5 lb. sledge to start
- Center as near as possible
- Avoid knots
- Preferable method would be a flat surface (flat paddle) to assure even insertion
- Seat star with sledge

Designed For:

4" Star-Lock -- Class 6 and Class 7

5" Star-Lock – Class 3, Class 4 and Class 5

6" Star-Lock – Class 1, Class 2 and Class H

PROTOP

- ProTop is installed using two 3.5 inch spiral galvanized nails and rubber washers.
- Usually installed in the field just before standing
- ProTop should be sized to the top of the pole to not extend past the perimeter.