



Build sides on a flat surface. Paint windows and doors first. Mask off. Paint brick in order shown on BoM. Note random brick coloring

Note PlasticWood used to fill in voids commonly found when using textured styrene.

www.VCLCo.com



Fair in roof and add saddle doublers to install roof panels to.



Finger plane can be used to fair in roof.

www.VCLCo.com





www.VCLCo.com

