
Assembly instruction for Ptfit point of purchase







3. Attach brochures box to top back piece and tap in pegs with hammer.



1. Assemble left side to back pieces & tap pegs into holes with hammer to connect back pieces to side



4. Use a phillips screw driver to attach dowels and wheels with supplied wood screws.



2. Assemble right side & tap pegs into other side back peices.

Notes:

Assembly Tools Needed:

- -Need hammer
- -Screw driver

Disassemby tools

- -Pliers or hammer and 3/16 punch
- -Use 3/16 punch and tap peg out.
- -To disassemble with pliers grip wood peg and pull out. There is a good chance you may damage peg so we include extra pegs just incase you have to take a peg out.
- -If you have pegs that are loose, try a different peg because the diameter are a little different.

Parts list

- -1 Relax back
- -1 Message back
- -1 Try me back
- -2 Small bottom brackets
- -2 Large botttom bracets
- -2 Double hook pieces
- -2 3/4 Dowels
- -4 Wheels
- -20 1/4 Dowels
- -4 Wood screws
- -2 Brochure holder & Brochures