## LAB DESIGNS ARCHITECTURAL LAMINATES

## **Continuous Pressed Laminate**

(Not a High Pressure Laminate)

Use normal high pressure laminate fabricator techniques when using this product and follow the instructions below.

- 1. Please handle with care, the product is thin.
- 2. Please remove from box/crate and let acclimate for 5-7 days before using.
- 3. After opening pallet or box lay laminate flat and put a heavy substrate on top to keep it from warping. Some warping can be extreme.
- 4. Never fabricate or store product under 60 degrees or above 90 degrees.
- 5. Leave your A/C or heater on at all times.
- 6. Never deliver finished product to a non-temperature controlled environment.
- 7. This product must always be balanced with a brown 0.6mm thick phenolic backer. High Pressure Laminate, Cabinet Liner, Paint, Melamine, Paper Back or Raw Back do not count as balanced.
- 8. Substrate must be MDF or Particle Board (nothing else)
- 9. Never use this product horizontally or in a high traffic area.
- 10. Never apply to dry wall without using substrate.