



Black Magic 155


This model does not include thermostatic control




Mounting Instructions-155 may be installed horizontally or vertically to the radiator

Assemble the brackets and threaded rods to the 155 fan according to the specific application. Mount the 155 with brackets using either the bolt-on or clamp-on method.

Bolt-on Method



Clamp-on Method



Notes:

Be sure to use star nuts to stabilize the threaded rods.

Do not over tighten to the radiator,damage may occur.

This fan is designed to mount as a puller.

Red motor wire should be positive +. Black motor wire should be negative -

The Flex-a-lite Limited Warranty

Flex-a-lite Consolidated, 7213-45th St. Ct. E. Fife, WA 98424, Telephone No. 253-922-2700, warrants to the original purchasing user, that all Flex-a-lite products to be free of defects in material and workmanship for a period of 365 days (**1 year**) from date of purchase. Flex-a-lite products failing within 365 days (**1 year**) from date of purchase may be returned to the factory through the point of purchase, transportation charges prepaid. If, on inspection, cause of failure is determined to be defective material or workmanship and not by misuse, accidental or improper installation, Flex-a-lite will replace the fan free of charge, transportation prepaid. **Flex-a-lite will not be liable for incidental, progressive or consequential damages.** Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights and you may have other rights, which vary from state to state. The Flex-a-lite warranty is in compliance with the Magnuson-Moss Warranty Act of 1975.