

CLEANING

- Please thoroughly clean your new Nomader bottle before first use - by hand with warm soapy filtered water or in the top rack of your dishwasher. Do not use any abrasive cleaning materials.
- For maximum freshness, fill your bottle with fresh cut lemons and filtered water and let it soak for 24 hours. Rinse and repeat as needed.
- Dust, lint or hair stuck to the outside of the bottle is easily removed with a quick rinse of water.

OPENING & CLOSING

- The hygienic spout cover prevents unwanted grime from getting onto the spout and into your drink. When not in use, close by turning clockwise to the "OFF" position. To open, turn counter-clockwise to the "ON" position.
- Remove the wide mouth lid to refill your bottle, add ice, or for access to clean the interior of the bottle.
- To prevent leaking, ensure spout cover and lid are fully tightened.

FOLDING

1. Deflate empty bottle by loosening spout cover. Ensure opening slot in hard plastic sleeve is aligned with strap.
2. Grip base of bottle and slide up sleeve until bottom of sleeve opening meets plastic latch at base of strap.
3. Roll up bottle from its bottom on opposite side of strap.
4. Wrap strap around rolled up bottle and attach metal clip to plastic latch.



PROTECTIVE SLEEVE

- The rigid plastic sleeve is designed to insulate your hand against heat from hot drinks and condensation from cold drinks. It also adds stability to the soft silicone body, providing for a more comfortable drinking experience.

HOT DRINKS

- Bottle can safely hold drinks at boiling temperature of 212°F.
- Always use the insulated plastic sleeve to safely handle hot drinks.
- Microwaving the bottle is not recommended.

FREEZING

- Bottle is resistant to freeze safe temperatures well below 32°F.
- Fill no more than 3/4 of bottle with water before freezing to allow for the expansion of water as it freezes.



Your purchase from us is fully backed by our lifetime warranty



Free from harmful toxins; BPA, lead, PVC, Phthalates