



Bored Locks

Template & Installation Instruction Guide

91067

11 Line Templates

Template	Category	Notes
Main Mounting Template Doc# 4527	Mounting Template	Works for all functions EXCEPT 93 & 94
Mounting Template For 93 & 94 Functions Doc# 4539	Mounting Template	Only for 93 & 94 functions
505 Strike Template Doc# 4421	Strikes	Full Lip
800 Strike Template Doc# 4131	Strikes	Lip Lengths: 1" 1-1/4" (Standard) 1-1/2" 1-3/4" 2"
808 Strike Template Doc# 4049	Strikes	Lip Lengths: 1-1/8" 1-1/4" (Standard) 1-3/8" 1-5/8" 1-7/8" 2-1/8" 2-3/8" 2-5/8" 2-7/8"



Template & Installation Instruction Guide

91067

11 Line Installation Instructions

Installation Instructions	Installation Category	Install Notes
11 Line All Functions Doc# A7469	Main Installation	All Functions (Except 93, 94, 94-2 Dummy Trims)
11 Line Dummy Trim Doc# A7470	Main Installation	Dummy Trim Functions ONLY (93, 94, 94-2)
11 Line T-Zone 11G38 Doc# A7497	Main Installation	11G38 Function ONLY
11 Line 50 Fuction Doc# A7608	Main Installation	11G50 Function ONLY
11 Line High Security Lever Doc# A7608	Main Installation	SL- Prefix High Security Lever
6010 Replacement Kit Doc# A6567	Main Installation	Replacing SARGENT 7600 Line with 11 Line
SARGENT LFIC Removable Core or Arrow, Best, Falcon Interchangeable Core Cylinder and Lever Removal Doc# A7471	Cylinder Related Instructions	(60, 63, 64) & (65-73, 70, 72, 73) Prefixes
Schlage® Fixed Core Cylinder Doc# A7476	Cylinder Related Instructions	30 Prefix ONLY
6300 Series Tailpiece Retainer for 11 Line Doc# A8188	Cylinder Related Instructions	6300 LFIC Core (63 Prefix)
ASSA ABLOY ACCENTRA® Fixed Core Spacer Doc# A8225	Cylinder Related Instructions	YC Prefix ONLY



Template & Installation Instruction Guide

91067

10X Line Templates

Template	Category	Notes
Main Mounting Template Doc# A8294	Mounting Template	Works for all functions EXCEPT 70 & 71
Mounting Template For 70 & 71 Functions Doc# 4756	Mounting Template	Only for 70 & 71 functions
BHW Mounting Template Doc# 4753	Behavioural Health (Anti Ligature)	Only use this template when using BHW
KP Mounting Template Doc# 4757	Keypad/Reader	Only use this template when using KeyPad
IN Mounting Template Doc# 4758	Keypad/Reader	Only use this template when using IN100/ IN120/IN220 Reader Technology
SN Mounting Template Doc# 4759	Keypad/Reader	Only use this template when using SN200/ SN210 Reader Technology
505 Strike Template Doc# 4421	Strikes	Full Lip
800 Strike Template Doc# 4131	Strikes	Lip Lengths: 1" 1-1/4" (Standard) 1-1/2" 1-3/4" 2"
808 Strike Template Doc# 4049	Strikes	Lip Lengths: 1-1/8" 1-1/4" (Standard) 1-3/8" 1-5/8" 1-7/8" 2-1/8" 2-3/8" 2-5/8" 2-7/8"

Bored Locks




SARGENT
ASSA ABLOY

Template & Installation Instruction Guide

91067

10X Line Installation Instructions

Installation Instructions	Installation Category	Install Notes
10X Line All Functions Doc# A8286	Main Installation	All Mechanical Functions
10X Electrified Functions Doc# A8351	Main Installation	Electrified Functions only (10XG70, 10XG71)
Latch Extension Assembly Doc# A8295	Main Installation	3-3/4" and 5" Backsets
SARGENT 4399 Exit Button Doc# A7864	Main Installation	Spring loaded momentary 2" square, exit button, mounted on a stainless steel single gang outlet box cover.
ElectroLynx Retrofit Kit Doc# A7738	Main Installation	Retrofit ElectroLynx® products to doors not already prepped with ElectroLynx® door harnesses
10X with BHW Trim Doc# A8334	Behavioural Health (Anti Ligature)	BHW Trim Only
KP 10X Installation Doc# A8355	Keypad/Reader	Only use this when using with KeyPad
IN100 10XLine Doc# A8357	Keypad/Reader	Only use this when using with IN100 Aperio™ Technology
IN100 Series EM01 Outside Escutcheon Replacement Doc# A8293	Keypad/Reader	Reader & Controller
IN120 & IN220 Series 10X Doc# A8356	Keypad/Reader	Only use this when using with IN120 or IN220 Technology
IN120 & Passport 1000 P2 Series Hard Powering Doc# WFMN10A	Keypad/Reader	91 Prefix Wifi Enabled Products
SN Series 10X Installation Doc# A8353	Keypad/Reader	Only use this when using with SN200 & SN210 Technology
Door Position Switch Doc# A7983	EM Related Instructions	Frame ONLY
Door Position Switch Doc# A8005	EM Related Instructions	HInge ONLY
52-2847 Weather Seal Conduit Doc# A7721	EM Related Instructions	For use on Non-Fire Rated Exterior doors with all KP or Profile Series stand alone keypad locksets
KP Series Controller Replacement Doc# A8288	EM Related Instructions	Controller Replacement 52-6085
KP Weatherization Kit Doc# A8289	EM Related Instructions	
IP-Enabled Quick Reference Guide Doc# WFMN3	EM Related Instructions	



Template & Installation Instruction Guide

91067

8X Line Templates

Template	Category	Notes
Main Mounting Template Doc# 4732	Mounting Template	Works for all functions
Dummy Trim Template Doc# 4733	Mounting Template	Dummy Trim Only
505 Strike Template Doc# 4421	Strikes	Full Lip
800 Strike Template Doc# 4131	Strikes	Lip Lengths: 1" 1-1/4" (Standard) 1-1/2" 1-3/4" 2"
808 Strike Template Doc# 4049	Strikes	Lip Lengths: 1-1/8" 1-1/4" (Standard) 1-3/8" 1-5/8" 1-7/8" 2-1/8" 2-3/8" 2-5/8" 2-7/8"

Bored Locks



SARGENT
ASSA ABLOY

Template & Installation Instruction Guide

91067

8X Line Installation Instructions

Installation Instructions	Installation Category	Install Notes
8X Line Install Doc# A8193	Main Installation	All Functions Except Dummy Trim
8X Line Dummy Knob Trim Doc# MEMN7	Main Installation	Dummy Trim Functions ONLY (8XU93)



Template & Installation Instruction Guide

91067

7 Line Templates

Template	Category	Notes
Main Mounting Template Doc# 4481	Mounting Template	Works for all functions
Dummy Trim Template Doc# 4481	Mounting Template	Dummy Trim Only
505 Strike Template Doc# 4421	Strikes	Full Lip
800 Strike Template Doc# 4131	Strikes	Lip Lengths: 1" 1-1/4" (Standard) 1-1/2" 1-3/4" 2"
808 Strike Template Doc# 4049	Strikes	Lip Lengths: 1-1/8" 1-1/4" (Standard) 1-3/8" 1-5/8" 1-7/8" 2-1/8" 2-3/8" 2-5/8" 2-7/8"

Bored Locks



SARGENT
ASSA ABLOY

Template & Installation Instruction Guide

91067

7 Line Installation Instructions

Installation Instructions	Installation Category	Install Notes
7 Line Install Doc# A7240	Main Installation	All Functions
6010 Replacement Kit Doc# A6567	Main Installation	Replacing SARGENT 7600 Line with 7 Line
SARGENT LFIC Removable Core or Arrow, Best, Falcon Interchangeable Core Cylinder and Lever Removal Doc# A6847	Cylinder Related Instructions	(60, 63, 64) & (65-73, 70, 72, 73) Prefixes
Schlage® Fixed Core Cylinder Doc# A6838	Cylinder Related Instructions	30 Prefix ONLY
7 Line Schlage® LFIC Doc# A8009A	Cylinder Related Instructions	SF- Prefix ONLY
6300 Series Tailpiece Retainer for 7 Line Doc# A8188	Cylinder Related Instructions	6300 LFIC Core (63 Prefix)

Bored Locks



SARGENT
ASSA ABLOY

Template & Installation Instruction Guide

91067

6500 Series Templates

Template	Category	Notes
Main Mounting Template Doc# 4430	Mounting Template	Works for all functions
505 Strike Template Doc# 4421	Strikes	Full Lip
800 Strike Template Doc# 4131	Strikes	Lip Lengths: 1" 1-1/4" (Standard) 1-1/2" 1-3/4" 2"
808 Strike Template Doc# 4049	Strikes	Lip Lengths: 1-1/8" 1-1/4" (Standard) 1-3/8" 1-5/8" 1-7/8" 2-1/8" 2-3/8" 2-5/8" 2-7/8"

Bored Locks



SARGENT
ASSA ABLOY

Template & Installation Instruction Guide

91067

6500 Series Installation Instructions

Installation Instructions	Installation Category	Install Notes
6500 Install Doc# A6913	Main Installation	All Functions
6500 Construction Plugs Doc# A7001	Cylinder Related Instructions	
6300 LFIC Tailpiece Retainer Instructions Doc# A8188	Cylinder Related Instructions	



Template & Installation Instruction Guide

91067

6 Line Templates

Template	Category	Notes
Main Mounting Template Doc# 4252	Mounting Template	Works for all functions EXCEPT 93 & 94
Mounting Template for functions 93 & 94 Doc# 4255	Mounting Template	Works for only 93 & 94
505 Strike Template Doc# 4421	Strikes	Full Lip
800 Strike Template Doc# 4131	Strikes	Lip Lengths: 1" 1-1/4" (Standard) 1-1/2" 1-3/4" 2"
808 Strike Template Doc# 4049	Strikes	Lip Lengths: 1-1/8" 1-1/4" (Standard) 1-3/8" 1-5/8" 1-7/8" 2-1/8" 2-3/8" 2-5/8" 2-7/8"

Bored Locks



SARGENT
ASSA ABLOY

Template & Installation Instruction Guide

91067

6 Line Installation Instructions

Installation Instructions	Installation Category	Install Notes
6 Line Installation Doc# A6286	Main Installation	All Functions
6 Line Installation (FRENCH) Doc# A6286	Main Installation	All Functions

Bored Locks



Template & Installation Instruction Guide

91067

DL Series Templates

Template	Category	Notes
DL Main Mounting Template Doc# 4584	Mounting Template	Works for all functions EXCEPT 93 & 94
DL Mounting Template for functions 93 & 94 Doc# A7931	Mounting Template	Works for only 93 & 94
RDL Main Mounting Template Doc# 4646	Mounting Template	Works for all functions EXCEPT 93 & 94
RDL Mounting Template for functions 93 & 94 Doc# 4666	Mounting Template	Works for only 93 & 94
505 Strike Template Doc# 4421	Strikes	Full Lip
800 Strike Template Doc# 4131	Strikes	Lip Lengths: 1" 1-1/4" (Standard) 1-1/2" 1-3/4" 2"
808 Strike Template Doc# 4049	Strikes	Lip Lengths: 1-1/8" 1-1/4" (Standard) 1-3/8" 1-5/8" 1-7/8" 2-1/8" 2-3/8" 2-5/8" 2-7/8"

Bored Locks



SARGENT
ASSA ABLOY

Template & Installation Instruction Guide

91067

DL Series Installation Instructions

Installation Instructions	Installation Category	Install Notes
DL Series Installation Doc# A7858	Main Installation	All Functions