



TEMPLATES & INSTALLATION INSTRUCTIONS GUIDE

Pull Side Closer Mounted on Door		
Arm Type	Template	Description
Regular	7349-0148	78-B/F-RA, w/ B/F-6 Adjustable Bracket, Non-Hold Open
	7349-0149	78-B/F-RA, w/ B/F-7 Offset Bracket, Non-Hold Open
Push Side Closer Mounted on Door		
Arm Type	Template	Description
Parallel	7349-0201	78-B/F-PA, w/ 1618 Soffit Plate, Non-Hold Open
	7349-0203	78-B/F-PA, w/ 2018B Soffit Plate, Non-Hold Open
	7349-0205	78-B/F-PA, w/ 2022 Angle Bracket & 1618 Soffit Plate, Non-Hold Open
	7349-0202	78-B/F-PA, w/ 2018 Soffit Bracket, Non-Hold Open
	7349-0206	78-B/F-PA, w/ 2018S Soffit Plate, Non-Hold Open
	7349-0209	78-B/F-PHA, Hold Open
	7349-0204	78-B/F-PA with 2018D Soffit Bracket, Parallel Arm, Non-Hold Open, with or without No. 88 Drop Plate
	7349-0208	78-B/F-PHA with 2022 Bracket, Parallel Arm, Hold Open
Parallel Rigid, Heavy-Duty	7349-0251	78-B/F-PRA, w/ 2019 Soffit Plate, Non-Hold Open or Hold Open
	7349-0252	78-B/F-PRA, w/ 2019S Spacer Block, Non-Hold Open or Hold Open
	7349-0255	78-B/F-PRA, w/ 6890 Support Bracket & 6891 Spacer Block, Non-Hold Open or Hold Open
	7349-0253	78-B/F-PRA, w/ 2019L Bracket, Non-Hold Open or Hold Open
	7349-0254	78-B/F-PRA, w/ 6890 Support Bracket, Non-Hold Open or Hold Open
	7349-0256	78-B/F-PRA, w/ 2019S & 6891 Spacer Blocks, Non-Hold Open or Hold Open
Unitrol®, Heavy-Duty	7349-1351	UNI78-B/F, w/ 6190 Bracket, Non-Hold Open or Hold Open, for Door Widths 28" - 32"
	7349-1353	UNI78-B/F, w/ 6190 Bracket, Non-Hold Open or Hold Open, Door Widths 33" - 41"
	7349-1355	UNI78-B/F, w/ 6190 Bracket, Non-Hold Open or Hold Open, Door Widths 42" - 48"
	7349-1352	UNI78-B/F, w/ 2022 Bracket (Flush Partitions), Non-Hold Open or Hold Open, Door Widths 28" - 32"
	7349-1354	UNI78-BF, w/ 2022 Bracket, (Flush Partitions), Non-Hold Open or Hold Open, Door Widths 33" - 41"

Experience a safer
and more open world



TEMPLATES & INSTALLATION INSTRUCTIONS GUIDE

Pull Side		
Arm Type	Template	Description
Regular	7349-0148	78-B/F-RA, w/ B/F-6 Adjustable Bracket, Non-Hold Open
	7349-0149	78-B/F-RA, w/ B/F-7 Offset Bracket, Non-Hold Open

Pull Side		
Arm Type	Installation Instruction	Description
Regular	80-9349-0001-020	78B/D, 78E/F, Non-Hold Open
	80-9349-0010-020	78B/D, 78E/F, Hold Open

Push Side		
Arm Type	Installation Instruction	Description
Parallel	80-9349-0001-020	78B/D, 78E/F, Non-Hold Open
	80-9349-0010-020	78B/D, 78E/F, Hold Open
Parallel Rigid, Heavy-Duty	80-9349-0060-020	78B/D-PRA, 78E/F-PRA, Non-Hold Open or Hold Open
Unitrol®, Heavy-Duty	80-9349-1040-020	UNI78B/D, UNI78E/F, Non-Hold Open or Hold Open

Experience a safer
and more open world