



Charging Your Devices



Recharging Your Power Bank





Note: If you have purchased Anker 100W Charging Base, you can use it to recharge the power bank.


Connecting the Power Bank to the App

1




Download and open the Anker app.

2




Switch to the Bluetooth interface by pressing the button.

3



Press the button twice to enable Bluetooth.


4



Search for Bluetooth in the app and connect to it.


Trickle-Charging Mode

1




Activate trickle-charging mode.

2




Charge your accessories in trickle-charging mode.

3



Exit trickle-charging mode.

Display Screen Guide



1. Remaining Battery
2. Remaining Battery Duration / Full Recharge Time
3. Bluetooth
4. Output
5. Input
6. Trickle-Charging Mode

Specifications

Cell Capacity	27,650mAh (3,950mAh × 7)
USB-C1 / C2 Input	5V ≡ 3A / 9V ≡ 3A / 15V ≡ 3A / 20V ≡ 5A / 28V ≡ 5A
Charging Base Input	21.5V ≡ 4.65A
USB-C1 / C2 Output	5V ≡ 3A / 9V ≡ 3A / 12V ≡ 1.5A / 15V ≡ 3A / 20V ≡ 5A / 28V ≡ 5A
USB-A Output	5V ≡ 3A / 9V ≡ 2A / 10V ≡ 6.5A / 12V ≡ 1.5A
USB-C1 + USB-C2 Output	240W Max
USB-C1 / C2 + USB-A Output	250W Max
USB-C1 + USB-C2 + USB-A Output	250W Max
Total Output	250W Max