








# PERFEKT

## CIĘCIE












## KARO A



|    |                      |                       |
|----|----------------------|-----------------------|
| PL | Instrukcja montażu   | Karta gwarancyjna     |
| D  | Aufbauanleitung      | der Garantieschein    |
| GB | Assembly instruction | Guarantee certificate |
| SK | Návod na montáž      | Záručný list          |



# Akcesoria - Accessories - die Accessoires

|                                                                                                           |                                                                                                              |                                                                                                       |                                                                                                         |
|-----------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------|
| <b>B</b><br><br>x44      | <b>C</b><br><br>x28         | <b>D</b><br><br>x28 | <b>G</b><br><br>x4   |
| <b>S</b><br><br>x4       | <b>D1</b><br><br>x8         | <b>D2</b><br><br>x8 | <b>Y</b><br><br>x1   |
| <b>P.</b><br><br>x4      | <b>E1</b><br><br>x2         | <b>E2</b><br><br>x2 | <b>H</b><br><br>x1   |
| <b>W1 4x27</b><br><br>x2 | <b>W3 3,5x16</b><br><br>x16 | <b>L</b><br><br>x8  | <b>M.</b><br><br>x30 |

