


**INSTRUCTION MANUAL/BEDIENUNGSANLEITUNG/
NOTICE D'UTILISATION/MANUAL DE INSTRUCCIONES DE USO**









Návod k sestavení ptačí klece / voliéry GRL BC-02



Text

Dodržujte prosím jednotlivé kroky k sestavení ptačí klece / voliéry.

PARTS LIST/STÜCKLISTE/PARTS LIST/LISTA DE PIEZAS

A  M6*30 12pcs	B1  4pcs	B2  4pcs
B3  8pcs	C  4pcs	D  1pc
E  1pc	F  1pc	G  1pc
H  2pcs	I  1pc	J  1pc
K  1pc	L  1pc	M  1pc

ASSEMBLY/MONTAGE/ASSEMBLAGE/MONTAJE

