




Massaggio Eccellente 2 Pro



User manual EN

Instrukcja obsługi PL

Thanks for purchasing this product. Please read this manual instruction carefully in order to know how to use this product correctly before operation. Please pay more attention to some important safety warning and keep this manual book properly for future use.

Note: Our Company reserves the right to revise the design and description of this product without any further notice. Please refer to the actual color of this product.

CONTENTS

Safety and maintenance	02
Safety warning	04
Name and function of components	06
Function	07
Method of usage	08
Product specification	16

Safety and maintenance



1. Important Safety Warning.

- Don't allow children to touch moveable part of this product.
- Please use well-grounding power supply suited to this product.
- Please pull out the plug after use or before cleaning to avoid injury or damage to the product.
- Please operate this product according to this manual instruction.
- Don't use accessories which are not recommended.
- Don't use this product outdoors.
- Please read this manual instruction carefully before operation.
- Any other usage that is not listed in this manual instruction is forbidden.
- 20 minutes of usage each time is recommended.
- Please don't use it if the leather is broken or damaged.
- Please don't use it if the cover or leather is damaged.
- Please don't use it if the radiator hole is covered or blocked.
- Please don't drop anything into this product.
- Please don't fall asleep while using this product.
- Please don't use it if drunk or feel unwell.
- Please don't use it within one hour after having meal.
- Please don't make the massage function too strong for avoiding Injury.

2. Environment for usage.

- Please don't use it under high temperature and moist environment such as bathroom.
- Please don't use it immediately while the environmental temperature changes sharply.
- Please don't use it under heavy-dusty or caustic environment.
- Please don't use it where there is not enough space or not good ventilation.

3. People who are not suitable to use this product.

- People who are suffering from osteoporosis are not suitable to use this product.
- People who are suffering from heart disease or carrying electronic medical equipment such as heart pacemaker are not suitable to use this product.
- People who are suffering from fever are not suitable to use this product.
- Pregnant women or women that are in menses period are not suitable to use this product.
- People who got injured or skin disease are not suitable to use this product.
- Children under 14-year old or people mentally unbalanced without being Supervised are not allowed to use this machine.
- People who are told by doctor to have rest or people who feel unwell are not suitable to use this product.
- People whose bodies are wet are forbidden to use this product.
- The appliance has a heated surface. Persons insensitive to heat must be careful when using the appliance.

Safety and maintenance

4. Safety.

- Check the voltage if it is suitable to the specification of this product.
- Don't use wet hand to pull the plug.
- Don't make water go inside this product to avoid electric shock or cause damage to this product.
- Don't damage the wires or change the circuit of this product.
- Don't use wet cloth to clean the electric parts such as switch and plug.
- Be away from this product under power cut state to avoid injury if the power comeback suddenly.
- Stop using this product while it works abnormal, and please consult local agent immediately.
- Stop using this product if you feel unwell, and please consult health care doctor.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its Service agent or similarly qualified persons in order to avoid a hazard.

5. Maintenance.

- This product should be maintained by certain appointed agents, users are prohibited to disassemble or maintain by themselves.
- Please don't forget to cut the power after usage.
- Don't use this product if the socket looses.
- If this product will be left unused for long, please curl up the wires and reserve this product in dry and dustless environment.
- Don't reserve this product under high temperature or near fire and avoid longtime direct sunshine.
- If the detachable cord / supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Please clean this product by dry cloth. Don't use thinner, benzene or alcohol.
- The mechanical components of this product are specially designed and made, it is not necessary to be specially maintained.
- Don't use edged res to thrust this product.
- Don't roll or pull this product above uneven ground, it should be lifted before moving.
- Please use it intermittently; don't make this product work continuously for long.


6. Solution of ordinary malfunctions.

- It is nature movement voice if the motor sounds while in usage.
- If the controller can't work normally, please check the plug and socket if they are connected strongly and make sure the switch is turned on.
- If the rated working time is over, the product will automatically activate the power-off button; If this product works continuously for long, the temperature protector will make the product automatically power-off, it should be used again after half an hour's rest.

Safety warning


Warning

When the footrest lifting, people should not apply pressure on the footrest to avoid the massage chair falling forward to damage the product or cause personal injuries.



Warning


Before sitting on the massage chair, make sure that the massage hand stays in the seat cushion position to avoid discomfort to the buttocks during the body pressing down and damage to the massage hand.



Safety warning


Warning

Do not strive to pull out the control cable or power cord during standby or power-on state to avoid product damaged or electrocution accidents. Advise you unplug the controller cable and power cord and put away after you use the chair.





Warning

When start the Zero Gravity lying function, be sure to check whether there are children and pets under the bottom of the footrest and backrest, may cause the product damaged or personal injuries.



Name and function of components




1. Head cushion
2. Upper arm air pressure component
3. Arm air pressure component
4. Salient massage with magnetic therapy
5. Remote controller and mobile phone holder
6. Seat cushion
7. Leg rest frame
8. Foot rest frame
9. Calf retaining plate
10. Back cushion
11. Armrest decoration
12. Armrest
13. Side cover
14. Back cover
15. Controller
16. PCB box cover
17. Caster
18. Power cord and plug
19. Fuse box
20. Hand controller cable socket
21. Power switch
22. Power cord socket

Function

- Designed with a set of vertically movable, four wheel driven muted intelligent massage hands.
- There are five kinds of simulated massage techniques: shiatsu, kneading, tapping, knocking, kneading and tapping.
- Set with six kinds of characterized auto massage function: comfort, ease, full body, neck& shoulder, back & waist massage, stretch.
- It has the upper body manual massage function (area, fixed point, full back, neck shoulder, back waist, five massage parts selection, each massage technique speed can be adjusted in three steps. In the fixed point and partial module state, the massage ball can move up and down to adjust the massage point accurately. In the state of tapping, shiatsu and knocking massage, the width between the two kneading balls is adjustable with three levels: wide, medium and narrow..
- Air pressure massage function with three modes: Full body air pressure, arms air pressure, leg air pressure, with 3 intensity adjustable.
- With sole roller massage function
- The footrest can be extended to suit different leg lengths.
- The motor drives the footrest and the backrest synchronically and lay down automatically two regulatory functions.
- The backrest of the massage chair should be kept at least 275 mm away from the wall.
- Back heating function: The carbon fiber is used as the infrared heat.
- Placed a high-energy magnet at each of the left and right heels.
- In the left and right palm air bags, there is a salient massage with a magnetic massage function.
- Natural magnet is placed at the heel of the heel.
- The SL-type backrest track fits the human body curve, and the backrest is in a zero-gravity state when lying down.
- The chair will be reset when switch off. The massage hands will be restore as well.

Method of usage

Note: The specific displays refer to the actual object of this product!




Method of usage

1. LCD display:
 - Display all massage functions
2. Power switch:
 - Turn on or Turn off all massage functions.
3. Pause button:
 - Stop or start all massage functions..
4. Timing button
 - Time setting
5. Auto lying Button
 - There are three automatic lying position, choose your favorite one.
6. Auto massage Button
 - Please refer to page 10 of this manual for details.
7. Air pressure mode Button
 - Turn on/off the air pressure massage function (refer to page 12 of this manual for details).
8. Manual massage button
 - Please refer to page 10 of this manual for details.
9. Sole roller button
 - Turn on/off sole roller massage function
10. Shoulder adjust button
 - Make the adjustment on shoulder acupressure points.
11. Lifting button
 - Rise up the backrest and lower down the footrest.
12. Lying button
 - Lower down the backrest and rise up the footrest.
13. Air pressure intensity button
 - Make the adjustment on air pressure intensity.
14. Heating
 - Turn on/off heating massage function

Method of usage


1. Switch power supply on



2.Start to massage

- ①. Press the power button to start massage.
- ②. The chair conduct a body scan and testing your shoulder position and massage point, waiting for detection to be completed
- ③. If the body scan deviates from the actual shoulder position, adjust the up and down buttons to the appropriate position. There are 10 levels to adjust, and you have 10 seconds to make the adjustment. After 10 seconds, enter in to massage automatically.

Button	Description	Display
	Move the massage balls upward to a suitable position	
	Move the massage balls downward to a suitable position	



During the body scan process (the shoulder position adjustment icon will be displayed on the screen of the controller and sounds "DiDi", and then press the shoulder position up and down keys to adjust the shoulder position). You can also press any of the six automatic massage function keys (comfort, ease, full body, neck shoulder, back waist, stretch) and start massage (you can skip step 4 directly).

- ④. Choose massage function and start massage

Method of usage

· Features automatics massage

Function	Button	Description	Display
Features automatics massage		Loosen the muscles.	F1 Auto
		Deep-tissue massage throughout key acupressure points to relax the sore area.	F2 Auto
		Full body massage, relaxing the sore areas.	F3 Auto
		Focus on the neck and shoulder area	F4 Auto
		Focus on the back waist area.	F5 Auto
		The footrest and backrest lifting together, combined with air pressure massage to stretch the legs, remove fatigue, and recover your body.	F6 Auto

· Upper body manual massage

Function	Button	Massage ball adjustment		Display
Massage		Shiatsu Speed, width		
		Kneading: Speed		
		Tapping: Speed, width		
		Kneading and tapping: speed		
		Knocking: Speed, width		
Speed		3 adjustable level		 Speed
Width		3 adjustable level		 Width
Back stretch		The massage hand stay in fixed positon		 H0
		The massage hand will move up and down in a partial position		 H1
		The massage hand will move up and down on full back		 H2
		The massage hand will move up and down on back and shoulder area		 H3
		The massage hand will move up and down on back and waist area		 H4
		Message position adjustment (in fixed point, partial mode, the massage position can be adjusted).	Message hand move up	
			Message hands go down	

Method of usage

· Air pressure massage

Function	Button	Description	Display
Air pressure mode		Full air pressure: air pressure massage on arm, leg and foot.	Arm  Feet 
		Arm: Air pressure massage focus on arm.	Arm 
		Legs: Air pressure massage focus on leg and foot.	Feet 
Intensity		3 levels adjustable	Arm  Feet 

· Foot roller manual massage function

Function	Button	Description	Display
Foot roller		The foot roller massage function turn on or off.	

· Heating

Function	Button	Description	Display
Heating		Press this button to turn on/off the back infrared heating, and it will be warm after turning on 3 minutes.	

· Pause/start massage button

Function	Button	Description	Display
Pauza / Start		Press this button during the massage, all massage actions are stop immediately (the timer will continue to count down), and press this button again, all the massage will be resume.	

· Backrest and calf position adjust

Function	Button	Description
Lifting button		Press and hold this button, it will raise the backrest and lower the footrest simultaneously, a "Di.Di sound indicate that it has reach the maximum position and stop. Press this button again while lifting, then immediately stop.
Lying button		Press and hold this button, it will lower the backrest and raise the footrest simultaneously, a "Di.Di sound indicate that it has reach the maximum position and stop. Press this button again while lifting, then immediately stop.
Automatic lying mode		When pressing this button, it will automatically place you into one position, total three position switch.


Method of usage

· Other manual functions

Function	Button	Description	Display
Timing		Timing adjustment, press one time, add 5 minutes, not more than 30 minutes. If it exceeds 30 minutes, it will return to 5 minutes.	<i>20min</i>


3. Turn off the power and stop massage.

- When pressing the power button during the massage, it will stop all the massage functions immediately, the backrest and footrest will go back to the default position. And when the massage time up, the massage hand will go back to the default position, all the massage function will stop, the backrest and footrest will not go back to the default position.
- Cut off the power of the whole machine. Figure (switch power off)




4. The calf installation.

1. After connecting the air hose and the wire harness on the calf and the massage chair, untie the fixed line belt and insert the connecting part into the frame. (Figure 1).
2. Place the calf fixing block on the two sides of the round tubes of the calf (Figure 2).




Method of usage

3. Hang the calf of the fixed block on the massage chair frame hook (Figure 3).
4. Then use 4 (each side two pcs) M4 screws to fasten the calf to the massage chair, check whether there is any abnormality, whether the pipeline is folded or not, and finish the installation (Figure 4).



5. Head cushions and backrest pad's dismounting and use manual


- The head cushion allows you to control the intensity of the neck and shoulder massage. You can decide whether to use the head cushion (Recommend to use). The backrest cushion and the backrest is connected by zipper (1), head cushion and the backrest cushion connected by the Velcro as show in the illustration (2).



Method of usage

6. Floor Protection


- Put the heavy massage chairs on the wood floor for a may damage the floor, so please place a carpet or other object to avoid this damage.



Caution: Do not move the chairs with its wheels on wood floor, rough ground or in a narrow space. Two people are required to lift the chair. During the lifting period, take the calf rest end sealing plate and backrest cover grooves as the force-bearing point(Please do not lift armrest directly.)

7. Method of movement

- Make sure that all wires are far above the ground, tilt the backrest backward to a certain degree (with the gravity center resting on the wheels), push the chair forward or backward with your hands and finally resume the chair to the normal position in a slow and gentle manner.




Note: During movement you must turn off the power first and then unplug the power cord and the controller cord.

Method of usage

8. The distance from the wall

- When you place the massage chair, the backrest should always be kept at least 275mm away from the wall. If the backrest is too close to the wall, it will collide the wall and cause damage to the product when it lifting down.



Product specification

Model: Massaggio Eccellente Pro

Configure: 2

Name: Massage Chair

Rated voltage: 220-240V~ 50Hz/60Hz ☐

Rated power input: 115W

Rated time: 20Min

Safety structure: Class I

Material introduction: PVC, PA, steel parts and electric & electron parts

MATERIAL	PU	LEATHER	CLOTH	WOOD

SAVE THESE INSTRUCTIONS


Dear user, you can contribute to environmental protection.
Be environmentally responsible and return your used equipment to the relevant collection point designated by your local administration. The materials used to manufacture the device may be valuable recyclable resources and, if disposed of incorrectly, can pose a risk to the natural environment.
Remember - do not dispose of the device together with your household waste.



EN



Massaggio Eccellente 2 Pro



Instrukcja obsługi

PL

Dziękujemy za zakup naszego produktu. Prosimy o dokładne przeczytanie instrukcji obsługi, aby przed uruchomieniem fotela masującego poznać wszystkie jego funkcje i możliwości. W szczególności prosimy o zapoznanie się z przeciwwskazaniami oraz zasadami bezpiecznego użytkowania.

Uwaga: Sprzedawca zastrzega sobie prawa do zmiany i interpretacji projektu fotela masującego. Kolor zilustrowany w instrukcji obsługi nie reprezentuje aktualnej kolorystyki fotela masującego.

Spis treści

Bezpieczeństwo i konserwacja	20
Ostrzeżenia bezpieczeństwa	22
Schemat fotela	24
Funkcje	25
Sposób użytkowania	26
Specyfikacja	34

Bezpieczeństwo i konserwacja



1. Ważne uwagi co do bezpieczeństwa

- Nie pozwalaj dzieciom dotykać ruchomych części tego fotela masującego.
- Używaj dobrze uziemionego zasilacza odpowiedniego dla tego produktu.
- Wyciągnij wtyczkę po użyciu lub przed czyszczeniem, aby uniknąć obrażeń lub uszkodzenia produktu.
- Obsługuj fotel masujący zgodnie z instrukcją obsługi.
- Nie używaj akcesoriów, które nie są zalecane.
- Nie używaj fotela masującego na zewnątrz.
- Przed rozpoczęciem użytkowania przeczytaj uważnie niniejszą instrukcję obsługi.
- Wszelkie inne zastosowania, które nie są wymienione w niniejszej instrukcji, są zabronione.
- Zaleca się każdorazowo 20 minut użytkowania.
- Nie używaj fotela, jeśli skóra lub pokrywa jest zepsuta lub uszkodzona.
- Nie używaj go, jeśli otwór chłodnicy jest zakryty lub zablokowany.
- Nie upuszczaj niczego nad fotelem masującym.
- Nie zasypiaj podczas korzystania z fotela masującego.
- Nie używaj fotela masującego, jeśli jesteś nietrzeźwy lub źle się czujesz.
- Nie korzystaj z masażu w ciągu godziny po posiłku.
- Nie ustawiaj dużej siły masażu w pierwszych etapach korzystania z fotela masującego.

2. Środowisko

- Nie używaj fotela masującego w pomieszczeniach o dużej temperaturze i wilgoci powietrza.
- Nie używaj fotela masującego od razu po gwałtownych zmianach temperatury.
- Nie używaj fotela masującego w miejscach silnie zakurzonych.
- Nie używaj fotela masującego w miejscach, gdzie nie ma wystarczającej przestrzeni, bądź cyrkulacji powietrza.

3. Przeciwwskazania do korzystania z fotela masującego.

- Osoby cierpiące na osteoporozę nie powinny korzystać z fotela masującego.
- Osoby cierpiące na choroby serca lub noszące elektroniczny sprzęt medyczny, taki jak rozrusznik serca, nie powinny korzystać z fotela masującego.
- Osoby z gorączką nie powinny korzystać z fotela masującego.
- Kobiety w ciąży lub kobiety w okresie menstruacyjnym nie powinny korzystać z tego fotela masującego.
- Osoby, które doznały obrażeń lub chorób skóry, nie powinny korzystać z tego produktu.
- Dzieci poniżej 14 roku życia lub osoby niezdolne do umyślowo bez nadzoru nie mogą korzystać z tego urządzenia.
- Osoby, którym lekarz zalecił odpoczynek lub które źle się czują, nie powinny korzystać z tego produktu.
- Osoby, których ciała są mokre, nie mogą używać tego produktu.
- Urządzenie ma podgrzewaną powierzchnię. Osoby niewrażliwe na ciepło muszą zachować ostrożność podczas korzystania z urządzenia.

Bezpieczeństwo i konserwacja

4. Bezpieczeństwo

- Sprawdź, czy napięcie jest zgodne ze specyfikacją tego produktu.
- Nie używaj mokrej ręki do wyciągania wtyczki.
- Nie wolno dopuścić do przedostania się wody do wnętrza tego produktu, aby uniknąć porażenia prądem lub uszkodzenia produktu.
- Uważaj na uszkodzenie przewodów.
- Nie używaj mokrej ściereczki do czyszczenia części elektrycznych, takich jak przełącznik i wtyczka.
- Nie zbliżaj się do produktu podczas odcięcia zasilania, aby uniknąć obrażeń, jeśli nagle nastąpi powrót zasilania.
- Nie używaj fotela masującego, gdy działa nieprawidłowo, natychmiast skontaktuj się ze sprzedawcą.
- Przerwij korzystanie z fotela masującego, kiedy poczujesz się źle, skonsultuj się z lekarzem.
- To urządzenie nie jest przeznaczone do użytku przez osoby (w tym dzieci) o ograniczonych zdolnościach fizycznych, sensorycznych lub umysłowych, lub bez doświadczenia i wiedzy, chyba że będą one nadzorowane lub poinstruowane w zakresie użytkowania urządzenia.
- Dzieci powinny znajdować się pod nadzorem, aby upewnić się, że nie bawią się urządzeniem.
- Jeśli przewód zasilający jest uszkodzony, musi zostać wymieniony przez producenta/serwisanta.

5. Konserwacja

- Wyłącz zasilanie przed czyszczeniem, w celu uniknięcia zranienia, bądź też uszkodzenia fotela masującego.
- Czyść fotel masujący za pomocą suchej szmatki lub specjalnych środków do tego przeznaczonych, nie używaj rozcieńczalnika, benzyny ani alkoholu.
- Jeżeli fotel masujący miałby być przez długi czas nieużywany, zwiń kabel, osłoń go i umieść w suchym pomieszczeniu.
- Nie przesuwaj fotela masującego po nierównej powierzchni.
- Pamiętaj o wyłączeniu fotela masującego po zakończeniu korzystania.
- Fotel masujący powinien być serwisowany wyłącznie przez serwis sprzedawcy.


6. Rozwiązania zwykłych usterek

- Naturalnym jest odgłos pracujących silowników w momencie używania fotela masującego.
- Jeżeli panel sterujący nie działa poprawnie, sprawdź, czy fotel masujący jest podłączony poprawnie oraz czy włącznik jest w pozycji „ON”.
- Jeżeli fotel masujący używany jest bez przerwy przez długi czas, to w momencie osiągnięcia wysokiej temperatury nastąpi automatyczne wyłączenie. Należy odczekać, co najmniej pół godziny, aby móc dalej korzystać z fotela masującego.

Ostrzeżenia dotyczące bezpieczeństwa


! Uwaga

Podczas podnoszenia podnóżka nie powinno się na niego naciskać, aby uniknąć przechylenia fotela masującego do przodu lub jego uszkodzenia.



! Uwaga


Przed korzystaniem z fotela masującego upewnij się, że ramię masujące pozostaje w górnej części oparcia tak, aby uniknąć dyskomfortu pośladków podczas nacisku na ciało i uszkodzenia samych ramion masujących.



Ostrzeżenia dotyczące bezpieczeństwa


! Uwaga

Nie staraj się wyciągać kabla sterującego lub przewodu zasilającego w trybie gotowości lub włączania, aby uniknąć uszkodzenia produktu lub porażenia prądem. Radzimy odłączyć kabel pilota i przewód zasilający oraz odłożyć go po użyciu fotela.




! Uwaga


Przed uruchomieniem funkcji Zero Gravity należy sprawdzić, czy pod podnóżkiem i oparciem znajdują się dzieci lub zwierzęta domowe, może to spowodować uszkodzenie fotela masującego lub obrażenia ciała.




Schemat fotela masującego



1. Poduszka
2. Masażer ramion
3. Masażer przedramion
4. Łagodny masaż magnetoterapią
5. Pilot zdalny i uchwyt na telefon
6. Siedzisko
7. Masażer łydek
8. Masażer stóp
9. Oslona przednia
10. Oparcie
11. Dekoracja podłokietnika
12. Podłokietnik
13. Oslona boczna



14. Oslona tylna
15. Pilot sterowania
16. Oslona sterownika
17. Włacznik bezpieczeństwa
18. Przewód zasilający z wtyczką
19. Bezpiecznik
20. Gniazdo na pilot
21. Włacznik zasilania
22. Gniazdo na przewód zasilający



- 19
- 20
- 21
- 22

Funkcje i działanie

- Wyposażony w zestaw mechanicznych, inteligentnych ramion z zestawem 4 kul masujących.
- 5 technik masażu: shiatsu, ugniatanie, rozbijanie, oklepywanie, oklepywanie z ugniataniem.
- 6 programów automatycznych: Comfort, Ease, Full Body, Neck & Shoulder, Back & Waist Massage, Stretch.
- Posiada funkcję manualnego masażu górnej części ciała (wybrany obszar, punktowo, całe plecy, ramiona przy szyi, talia pleców). Szybkość prowadzenia masażu można regulować w trzech poziomach. W masażu punktowym i częściowym możliwość dokładnego wybrania miejsca prowadzenia masażu. Przy masażu ostukującym (tapping), shiatsu i oklepywaniu (knocking) szerokość między dwiema kulkami ugniatającymi jest regulowana w trzech poziomach: szerokim, średnim i wąskim.
- Funkcja masażu powietrznego z trzema trybami: na całym ciele, na ramionach, na nogach, z 3 regulowanymi intensywnościami.
- Funkcja masażu stóp rolkami masującymi.
- Podnózek dostosowuje się do wzrostu użytkownika.
- Podnózek i oparcie poruszają się synchronicznie. Istnieje możliwość ich automatycznej regulacji.
- Oparcie fotela do masażu powinno znajdować się w odległości co najmniej 275 mm od ściany.
- Funkcja ogrzewania IR - na podczerwień.
- W lewej i prawej poduszce powietrznej dłoni znajduje się dodatkowo masaż z funkcją magnetoterapii.
- Magnes wysokoenergetyczny znajduje się w okolicach obu pięt masażera stóp.
- Masażer pleców typu SL dopasowuje się do krzywej ludzkiego ciała, a oparcie podczas leżenia znajduje się w pozycji Zero Gravity.
- Po wyłączeniu fotel powraca do ustawień startowych. Ramiona masujące także powrócą do pozycji początkowej.

Sposób użytkowania

Uwaga: Przedstawiony wyświetlacz odnosi się do tego konkretnego produktu.



Sposób użytkowania

1. Wyświetlacz:
 - Pokazuje wszystkie funkcje fotela.
2. Przycisk uruchamiania fotela
 - Włącza i wyłącza wszystkie funkcje fotela.
3. Przycisk pauzy:
 - Wstrzymanie wszystkich funkcji fotela.
4. Przycisk długości masażu.
 - Ustawienie czasu prowadzonego masażu
5. Przycisk automatycznego rozkładania fotela do pozycji leżącej
 - Wybierz jedną z trzech pozycji leżących jako swoją ulubioną.
6. Przycisk masażu automatycznego.
 - Więcej informacji na stronie 11 tej instrukcji.
7. Przycisk masażu powietrznego
 - Włączanie i wyłączanie funkcji masażu powietrznego (więcej informacji na stronie 12 tej instrukcji).
8. Przycisk masażu manualnego
 - Więcej informacji na stronie 11 tej instrukcji.
9. Przycisk masażu rolkowego stóp
 - Włączanie i wyłączanie funkcji masażu rolkowego stóp.
10. Przycisk regulacji wysokości ramion masujących
 - Możliwość korekty ustawienia ramion masujących.
11. Przycisk podnoszenia fotela masującego
 - Podniesienie oparcia do góry i obniżenie podnóżka.
12. Przycisk pochylania fotela masującego
 - Opuśzczenie oparcia do dołu i podniesienie podnóżka.
13. Przycisk intensywności masażu powietrznego
 - Regulacja siły nacisku masażu powietrznego.
14. Ogrzewanie
 - Włączanie i wyłączanie funkcji ogrzewania.

Sposób użytkowania

· Opis automatycznych programów masażu


Funkcja	Przycisk	Opis działania	Ekran
Programy automatyczne		Spokojny masaż, rozluźniający mięśnie.	F1 Auto
		Głęboki masaż, relaks w obszarach bólu.	F2 Auto
		Kompleksowy masaż całego ciała.	F3 Auto
		Masaż na górne partie kręgosłupa.	F4 Auto
		Masaż na dolne partie kręgosłupa, uda i pośladki.	F5 Auto
		Podnóżek i oparcie unoszą się w połączeniu z masażem powietrznym, aby rozciągnąć nogi, usunąć zmęczenie i zregenerować siły.	F6 Auto

· Techniki masażu górnych partii ciała

Funkcja	Przycisk	Regulacja pracy ramion masujących		Ekran
Techniki manualne		Shiatsu: Szybkość, szerokość		
		Ugniatanie: Szybkość		
		Oklepywanie: Szybkość, szerokość		
		Ugniatanie z oklepywaniem: Szybkość		
		Rozbijanie: Szybkość, szerokość		
Szybkość		3 poziomy dopasowania		
Szerokość		3 poziomy dopasowania		
Masaż pleców		Stała pozycja masażu (fixed), punktowy		 H0
		Mały obszar masażu (partial), częściowy		 H1
		Całościowy masaż pleców (overall)		 H2
		Masaż górnych partii ciała		 H3
		Masaż dolnych partii ciała		 H4
		Ustawienie pozycji mechanizmu masującego (pomiędzy punktowym i częściowym masażem)		Przesuwa mechanizm w górę
				Przesuwa mechanizm w dół

Sposób użytkowania


1. Włącz fotel, przełączając włącznik w pozycję ON



2. Start masażu

1. Wciśnij przycisk włączania (Power).
2. Mechanizm przeprowadzi skanowanie linii kręgosłupa oraz wyszuka najwyższy punkt górnych partii ciała, do którego będzie odbywać się masaż.
3. Jeżeli mechanizm nie jest dopasowany do pozycji ramion, można go ustawić za pomocą przycisków podnoszących lub opuszczających mechanizm, istnieje 10 poziomów. Program automatyczny uruchamia się po 10 sekundach od ustawienia wysokości ramion.

Przycisk	Opis działania	Ekran
	Przesuń mechanizm do góry, aby osiągnąć poziom ramion	
	Przesuń mechanizm w dół, aby osiągnąć poziom ramion	



Podczas skanowania ciała ikona regulacji pozycji barku zostanie wyświetlona na ekranie pilota i usłyszysz dźwięk „DiDi”, następnie naciśnij klawisze pozycji barku w górę i w dół, aby ustawić pozycję barku. Możesz także nacisnąć dowolny z sześciu klawiszy funkcyjnych automatycznego masażu (comfort, ease, full body, neck shoulder, back waist, stretch) i rozpocząć masaż. Poniższy krok 4 możesz pominąć.

4. Wybierz odpowiednią funkcję i rozpocznij masaż.

Sposób użytkowania

· Masaż poduszkami powietrznymi

Funkcje	Przycisk	Opis działania	Ekran
Tryb masażu poduszkami powietrznymi		Masaż poduszkami powietrznymi całego ciała: masaż poduszkami na ręce oraz nogi.	Arm  Feet 
		Ramiona: masaż poduszkami na ręce.	Arm 
		Nogi: masaż poduszkami na łydki i stopy.	Feet 
Intensywność		3 poziomy dostosowania.	Arm  Feet 

· Funkcja masażu rollkowego stóp

Funkcje	Przycisk	Opis działania	Ekran
Rolki na stopy		Włączenie i wyłączenie masażu rollkowego stóp.	

· Ogrzewanie

Funkcje	Przycisk	Opis działania	Ekran
Ogrzewanie		Ogrzewanie oparcia promieniami podczerwonymi, odczuwalne po trzech minutach.	

· Pauza/Start masażu

Funkcje	Przycisk	Opis działania	Ekran
Pauza / Start		Naciśnij ten przycisk podczas masażu, wszystkie czynności zostaną natychmiast zatrzymane (minutnik będzie dalej odliczał), a następnie naciśnij ten przycisk ponownie, aby masaż został wznowiony.	

· Funkcje ustawienia fotela

Funkcje	Przycisk	Opis działania
Pozycja siedząca		Przytrzymaj przycisk, a fotel będzie wracać do pozycji siedzącej do momentu, w którym puścisz przycisk. Jeżeli osiągniesz maksymalną pozycję, fotel wyda sygnał dźwiękowy.
Pozycja leżąca		Przytrzymaj przycisk, a fotel będzie schodził do pozycji leżącej do momentu, w którym puścisz przycisk. Jeżeli osiągniesz maksymalną pozycję, fotel wyda sygnał dźwiękowy.
Zero Gravity		Włączając ten przycisk, fotel przechodzi do pozycji Zero Gravity. Jest to pozycja w pełni leżąca.

Sposób użytkowania

· Inne manualne funkcje

Funkcje	Przycisk	Opis działania	Ekran
Czas		Ustawienie długości masażu, jedno wciśnięcie wydłuża go o 5 min., max. do 30 min. Przekroczenie tego czasu cofa do 5 min.	<i>20min</i>

3. Wyłączenie zasilania i zatrzymanie masażu.


· Aby zakończyć masaż przed upływem czasu, na jaki został zaprogramowany, wciśnij czerwony przycisk. Masaż zostanie natychmiast zatrzymany, podnóżek i oparcie powróci do pozycji siedzącej.

Po upływie zaprogramowanego czasu masaż zostanie zatrzymany, a fotel masujący pozostanie w wybranej pozycji.




4. Instalacja podnóżka.

1. Podłącz kostkę elektryczną oraz przewody powietrzne z masażera stóp do głównej konstrukcji fotela masującego. (rys. 1)
2. Umieść uchwyt mocujący (tuleja mocująca) masażer stóp po dwóch stronach okrągłych rurek (rys. 2).




Sposób użytkowania

3. Umieść masażer stóp na uchwycie łączeniowym przy ramie fotela (rys. 3).
4. Następnie 4 śrubami (po każdej stronie 2 szt.) przymocuj i skręć ze sobą oba elementy (rys. 4). Sprawdź, czy występują jakiekolwiek nieprawidłowości niezgodne z instrukcją powyżej i zakończ montaż.



5. Montaż/demontaż poduszki pod głowę i górną partię pleców.


- Używanie poduszek może zredukować intensywność masażu ramion i szyi.
- Możesz zdecydować, którą z poduszek chcesz zdemontować (rekomendowane jest używanie poduszki osłaniającej głowę). Pokrycie oparcia demontowane jest za pomocą zamka błyskawicznego (Rysunek 1). Poduszka ochraniająca głowę demontowana jest za pomocą rzepu (Rysunek 2).



Sposób użytkowania

6. Ochrona podłoża


· Używanie fotela masującego na drewnianej podłodze może ją zniszczyć. Zaleca się stosowanie dywaników bądź innych podstaw, żeby zapobiec uszkodzeniom podłogi.



Uwaga: Nie przesuwaj fotela na kółkach po drewnianej podłodze, nierównym podłożu lub w wąskiej przestrzeni. Do podniesienia fotela potrzebne są dwie osoby. Nie podnoś fotela bezpośrednio za podłokietniki, staraj się korzystać z elementów stelaża.

7. Sposoby przemieszczania

Upewnij się, że wszystkie przewody znajdują się nad ziemią, przechyl oparcie do pewnego stopnia do tyłu (ze środkiem ciężkości spoczywającym na kołach), popchnij fotel do przodu lub tyłu, a na końcu postaw fotel w normalnej pozycji w powolny i delikatny sposób.




Uwaga: Podczas przesuwania fotela należy najpierw wyłączyć zasilanie, a następnie odłączyć przewód zasilający i przewód pilota.

Sposób użytkowania

8. Odległość od ściany

Po ustawieniu fotela do masażu oparcie zawsze powinno znajdować się w odległości co najmniej 275 mm od ściany. Jeśli oparcie jest zbyt blisko ściany, zderzy się z nią i spowoduje uszkodzenie produktu podczas podnoszenia.



Specyfikacja fotela masującego

Model: Massaggio Eccellente Pro

Wersja: 2

Nazwa: Fotel masujący

Napięcie: 220-240V~ 50Hz/60Hz



Pobór mocy: 115W

Rekomendowany czas pracy: 20Min

Klasa bezpieczeństwa: Klasa I

Zastosowane materiały: PVC, PA, części stalowe, elektryczne i elektroniczne

MATERIAŁ	PU	SKÓRA	TRANINA	DREWNO

ZACHOWAJ INSTRUKCJE

Drogi użytkowniku, możesz przyczynić się do ochrony środowiska.
Bądź ekologicznie odpowiedzialny i zużyte urządzenie oddaj do odpowiedniego punktu składowania wyznaczonego przez lokalną administrację.
Użyte do produkcji urządzenia materiały mogą być cennym surowcem wtórnym, a gdy są niewłaściwie utylizowane mogą być niebezpieczne dla środowiska.
Pamiętaj - nie wyrzucaj urządzenia wraz z odpadami komunalnymi.

