

# Flame aromatherapy machine


## USER MANUAL

Please read this manual carefully before use to ensure that the product can be used correctly

## Instructions

- Aromatherapy function: add water into the water tank (not exceeding the water level line), add an appropriate amount of essential oil, and briefly press the atomization switch button to turn on aromatherapy atomization; Short press again to stop atomization.
- Lighting function: short press the light switch button to turn on the flame atmosphere light; Press and hold again to increase the brightness by 30%; Short press again; Turn off the flame atmosphere light.
- Protection function: built in water shortage protection chip, automatically stop working after detecting no water.

## Product Diagram



## Product Specification

Model: DQ701	Weight: 90g
Current: $\leq 900\text{mA}$	Input: DC5.0V/2A
Rated Power: $\leq 4.5\text{W}$	Size: 171x75x101mm
Tank capacity: 180mL	Raw Material: ABS/PP/PCBA
Spray Volume: 15–20mL/hr	Standard sheet: GB4706.1–2005
Made in China	GB4706.48–2009

## Product Contents

AtomizerX1、Type-C cableX1、ManualX1

## Note

- The maximum water volume of the water tank is 180 ml, and the water injection volume shall not exceed the maximum water level indication line, otherwise the atomization effect will be affected or water leakage will cause damage to the machine.
- Please use the attached Type-C 2A power cord. If you use a substitute power cord, you must note that the current specification is 2a, otherwise the atomization effect will be affected.
- Please fill the atomizer with purified water to avoid damage to the function of the atomizer due to impurities in the water, so as to achieve the best maintenance effect.
- During operation, the sound inside the water tank is the sound of atomization, which is a normal phenomenon.