

ARON SHOE SHELF INSTRUCTIONS

WARNINGS:

- before assembly and use, read this manual,
- before assembly, make sure you have all the assembly elements,
- keep the instructions, as they may be useful in the future,
- keep the assembly elements and packaging away from children, there is a risk of suffocation!
- do not allow children to unfold and fold the shelf,
- it is not recommended to fold and unfold the shelf repeatedly, it may reduce its stability,
- the product is not a toy,
- do not climb on the shelf

USE:


- the shelf should be used on a hard, even surface,
- the maximum load of the each shelf is 5kg,
- the product is for indoor use,

CLEANING AND MAINTENANCE:

The shelf should be cleaned with a damp, soft cloth.

Do not use strong detergents or sharp tools to clean the shelf


PARTS:



ASSEMBLY INSTRUCTIONS:


The shelf can be assembled in 3 types:

1 TYPE




AX40 PCS
B X 2 PCS
CX28 PCS
DX10 PCS
E X 5 PCS
F X 4 PCS

2 TYPE



AX40 PCS
B X 2 PCS
CX40 PCS
DX15 PCS
E X 5 PCS
F X 4 PCS

3 TYPE



AX40 PCS
B X 2 PCS
CX34 PCS
DX13 PCS
E X 5 PCS
F X 4 PCS

INSTRUKCJA REGAŁ NA BUTY ARON

OSTRZEŻENIA:

- przed rozpoczęciem montażu oraz użytkowania należy zapoznać się z niniejszą instrukcją,
- przed montażem upewnij się, że masz wszystkie elementy montażowe,
- instrukcje należy zachować, ponieważ może przydać się w przyszłości,
- elementy montażowe oraz opakowania należy trzymać z dala od dzieci, istnieje ryzyko uduszenia!
- nie należy zezwalać dzieciom na rozkładanie i składanie półki,
- nie zaleca się wielokrotnego składania i rozkładania półki, może przyczynić się to do zmniejszenia jej stabilności,
- produkt nie jest zabawką,
- nie wspinać się na regał

UŻYTKOWANIE:


- regał należy użytkować na twardej, równej powierzchni,
- maksymalne obciążenie każdej półki to 5kg,
- produkt do użytku wewnątrz pomieszczeń,

CZYSZCZENIE I KONSERWACJA:

Półkę należy czyścić wilgotną, miękką szmatką.

Nie używać silnych detergentów oraz ostrych narzędzi do czyszczenia półki


ELEMENTY MONTAŻOWE



INSTRUKCJA MONTAŻU:


Regał można złożyć na 3 sposoby:

1 SPOSÓB




AX40 PCS DX10 PCS
B X 2 PCS E X 5 PCS
CX28 PCS F X 4 PCS

2 SPOSÓB



AX40
B X 2
CX40
DX15
E X 5
F X 4

3 SPOSÓB



AX40 PCS
B X 2 PCS
CX34 PCS
DX13 PCS
E X 5 PCS
F X 4 PCS