







SERIA SP

- KRUSZARKI PIERŚCENIOWE
- MODULAR PILE BREAKERS



A



(1) Optymalna kombinacja koparka - osprzęt
Optimum excavator - equipment combination

(2) Możliwa kombinacja koparka - osprzęt
Possible excavator - equipment combination



		SP 07	SP 08	SP 09	SP 10	SP 11
	kg.	2325	2655	2990	3320	3655
A	mm.	2300	2500	2700	2900	3100
	mm.	450-600	650-800	850-1000	1050-1200	1250-1400
	mm.	210	210	210	210	210
N°	n°	7	8	9	10	11
max	bar	350	350	350	350	350
	l/min.	180	200	220	250	270

		SP 12	SP 13	SP 14
	kg.	3985	4320	4650
A	mm.	3300	3500	3700
	mm.	1450-1600	1650-1800	1850-2000
	mm.	210	210	210
N°	n°	12	13	14
max	bar	350	350	350
	l/min.	300	320	350

