

INSTRUKCJA OBSŁUGI

BOJKA DO PŁYWANIA BOJA ASEKURACYJNA GWIZDEK 28 L

PARAMETRY TECHNICZNE

- Tworzywo: plastik
- Pojemność: 28 L
- Wyporność: 18 kg
- Maksymalne obciążenie: 9 kg

OBSŁUGA

1. Upewnij się, że powietrze jest całkowicie spuszczone z boi.
2. Włóż do środka potrzebne przedmioty. Nie zaleca się pakowania przedmiotów o twardych i ostrych rogach.
3. Zawień górną część worka do oznaczonego moment.
4. Zepnij dwa końce za pomocą klamry.
5. Nadmuchać boję, aż jej powierzchnia będzie gładka.
6. Przymocuj boję do siebie smyczą w pasie.

Aby zwiększyć bezpieczeństwo urządzeń elektrycznych i innych delikatnych przedmiotów zalecamy spakować je do dodatkowego wodoodpornego pojemnika przed umieszczeniem ich w boi.

PRZECHOWYWANIE I KONSERWACJA

- Przechowuj z dala od źródeł ciepła, gdyż mogą one prowadzić do trwałego uszkodzenia produktu.
- Po każdym użyciu dokładnie umyj i wysusz produkt.
- Produkt należy przetrzeć miękką ściereczką z dodatkiem lekkiego środka myjącego, np. płynu do mycia naczyń.
- Nie należy szorować produktu ostrą częścią gąbki lub przy użyciu szcetek i druciaków, gdyż mogą one prowadzić do trwałego uszkodzenia powierzchni produktu.
- Produktu nie należy czyścić przy użyciu alkoholu, gdyż mogą one prowadzić do miejscowego odbarwienia produktu.
- Produktu nie należy czyścić przy użyciu acetonu, gdyż może on prowadzić do poważnego uszkodzenia produktu.
- Produkt należy chronić przed nadmiernym dostępem promieni słonecznych, gdyż mogą one prowadzić do powstania odbarwień.
- Po umyciu produkt należy przetrzeć suchym ręcznikiem papierowym lub miękką ściereczką.
- Nie należy suszyć produktu w pobliżu źródeł ciepła, gdyż może to prowadzić do odkształcenia się produktu.

OSTRZEŻENIA

1. Produkt nie jest zabawką.
2. Produkt przeznaczony dla osób potrafiących pływać.
3. Produkt należy czyścić zgodnie z zaleceniami znajdującymi się w instrukcji.
4. Należy regularnie kontrolować stan produktu. W przypadku stwierdzenia jakichkolwiek nieprawidłowości należy natychmiast przerwać korzystanie.
5. Uszkodzony produkt należy zutylizować zgodnie z lokalną polityką gospodarowania odpadami.
6. Instrukcja zawiera ważne informacje, należy więc zachować ją na wypadek wystąpienia jakichkolwiek wątpliwości.

KX3122 BOJKA DO PŁYWANIA BOJA ASEKURACYJNA GWIZDEK 28 L

Producent: KIK Sp. z o. o. Sp. K. Aleja 1000 – lecia Państwa Polskiego 8, 15 – 111 Białystok

USER MANUAL

SWIMMING BUOY SAFETY BUOY WHISTLE 28 L

TECHNICAL PARAMETERS

- Material: plastic
- Capacity: 28 L
- Buoyancy 18 kg
- Maximum load: 9 kg

OPERATION

1. Make sure the buoy is completely deflated.
2. Place the necessary items inside. It is not recommended to pack items with hard and sharp corners.
3. Roll up the top of the bag to the indicated moment.
4. Fasten the two ends with a buckle.
5. Inflate the buoy until its surface is smooth.
6. Fasten the buoy to yourself with a lanyard around your waist.

To increase the safety of electrical devices and other delicate items, we recommend packing them in an additional waterproof container before placing them in the buoy.

STORAGE AND MAINTENANCE

- Store away from heat sources, as they may lead to permanent damage to the product.
- Wash and dry the product thoroughly after each use.
- The product should be wiped with a soft cloth and a light detergent, e.g. dishwashing liquid.
- Do not scrub the product with a sharp part of a sponge or with brushes and scourers, as they may lead to permanent damage to the surface of the product.
- The product should not be cleaned with alcohol, as they may lead to local discolouration of the product.
- The product should not be cleaned with acetone, as it may lead to serious damage to the product.
- The product should be protected from excessive sunlight, as it may lead to discolouration.
- After washing, the product should be wiped with a dry paper towel or soft cloth.
- Do not dry the product near heat sources, as this may lead to deformation of the product.

WARNING

1. This product is not a toy.
2. This product is intended for people who can swim.
3. The product should be cleaned according to the instructions in the manual.
4. The product should be checked regularly. If any irregularities are found, discontinue use immediately.
5. Damaged products should be disposed of in accordance with local waste management policies.
6. The manual contains important information, so keep it in case of any doubts.