


Instructions

How to set your individual combination:

1. Set the dials to factory setting 0-0-0 and turn the knob clockwise to open the case.
2. Open the lid of the case and turn the small metal snap on the inside of the lid from position A to B.
3. With the lid still open, set the three dials to your desired, individual combination.
4. Return the metal snap from position B to A.
5. Your new combination is set.




Note: This product must be stored and used in a dry and secure environment. Protection of your valuables may not be ensured unless the case is secured on a fixed object.

Attention: Keep this product away from children.

There are two ways to secure the case:

1. Using the supplied steel cable
 - a) Open the case (see instructions above)
 - b) Loop the end of the cable with the small eyelet round your fixing object and then put the small eyelet through the larger one.
 - c) Put the small eyelet (incl. metal rivet) into the case.
 - d) Lock the case.
2. Pre-drilled mounting holes (on the bottom of the case)
 - a) Open the case (see instructions above)
 - b) Remove the foam inlay from the bottom.
 - c) Install the case on your desired position by using proper mounting material.



(Mounting material is not supplied)

Max Fuchs AG
Industriestraße 1
94078 Freyung
Germany

Item No.: 27171