


EXPLODED VIEW



SPARE PARTS

ITEM	ART.NO.	DESCRIPTION
1	910-0202-01	WASHER
2	910-0202-02	H/R KEY
3	910-0202-03	SPRING PIN (3 X 10)
4	910-0202-04	O-RING (P11)
5	910-0202-05	SPRING PIN (2 X 5)
6	910-0202-06	SPRING PIN (3 X 5)
7	910-0202-07	SPRING WASHER
8	910-0202-08	SNAP RING (STW-10)
9	910-0202-09	BEARING (6000ZZ)
10	910-0202-10	SCREW (M3 X 10)
11	910-0202-11	NUT (M3)
12	910-0202-12	BODY COVER
13	910-0202-13	U-BEARING CASE
14	910-0202-14	CYLINDER
15	910-0202-15	VANE
16	910-0202-16	VALVE STEM
17	910-0202-17	SEAL WASHER
18	910-0202-18	TIP VALVE
19	910-0202-19	VALVE LEVER
20	910-0202-20	VALVE SPRING
21	910-0202-21	INLET BUSHING
22	910-0202-22	O-RING (1.0 X 4)
23	910-0202-23	ROTOR
24	910-0202-24	MUFFLER ASSY
25	910-0202-25	BODY
26	910-0202-26	L-BEARING CASE
27	910-0202-27	LOCK RING
28	910-0202-28	SHAFT
29	910-0202-29	BALANCER SHAFT
30	910-0202-30	SNAP RING (RTW-26)
31	910-0202-31	HEX. BOLT (M5 X 15)
32	910-0202-32	SKIRT BAND
33	910-0202-33	RUBBER COVER
34	910-0202-34	HEX. BOLT (M4 X 8)

SPARE PARTS

ITEM	ART.NO.	DESCRIPTION
35	910-0202-35	O-RING (KS5)
36	910-0202-36	BACK-UP PAD 72 X 116 MM
42	910-0202-42	BEARING (6000RS)
43	910-0202-43	SPRING PIN (3 X 10) 1
44	971-0035	INTERFACE PAD (SPECIAL CUSHION PAD)

MACHINE & ACCESSORIES

ART.NO.	DESCRIPTION
910-0202	ORBITAL SANDER
910-0202-36	BACK-UP PAD 72 X 116 MM
971-0035	SUPER ASSILEX INTERFACE PAD