

2. Click "New User Registration" and

complete the registration with your

mobile phone number or email


address. When the mobile phone

please use the email to register

and password to log in to the APP.

cannot receive the verification code,

3. After registration, enter the account



to scan the device binding code again.

Product Description

extraordinary product.

2.Max noise: ≤50db

1.Material: Food-grade silicone

3.Battery:170mAh rechargeable lithium battery

This product has an elegant appearance and perfect touch. It has

super strong vibration and multiple vibration modes. You will get

protection are part of our design philosophy. We hope to provide the

ON/OFF

Click the plus sign to scan the identification code

vigorous sexual stimulation. Product safety and environmental

user with an excellent experience. It is destined to be an

4. Power : USB 5V 150mA DC charging ,charging time about 1H, use time



When product is charging, the LED will be flashing When a solid light appears, charging is complete *When being charged, the toy must be in shutdown state and cannot My device

Put the DC charging plug into the

hole in the motor part to charge.

or other charger(output:5V=1A or

5V=1.5A).

Then insert the USB charging plug

into the USB port of your computer

I. Download and install "Love Spouse" APP 1. Search for "Love Spouse" in App Store, download and install. 2. Scan the QR code with your mobile phone, and follow the prompts to download and install the "Love Spouse" APP. Android system 1. Search for "Love Spouse" in Google Store, download and install (It is recommended to use this method for download) 2. Scan the QR code with your mobile phone and follow the prompts to download and install the "Love Spouse" APP. V. Mode introduction 1. Classic mode: Click any icon on the Classic Music Delimit Shake APP, and the device will start the corresponding vibration frequency. At the same time, the icon on the APP will flash, click this icon again, the device



2. Music mode: Click on the music mode or slide the operation interface of the APP to enter the music mode. The APP will automatically search for the music player in the mobile phone. If you click on a music player to play music, the device will vibrate as the music changes. If you want to stop the music mode, click or slide to other control interface. If the sound of the mobile phone playing music is too low, it may not be able to drive the device to vibrate. Iphone can only use the music player that comes with the system.

Listening to music on your phone... Please select the application to open **1** HUAWEI Music QQMusic

Add buddy

F All - Age

3. Delimit mode: Click on the swipe mode or slide the operation interface of the APP to enter the swipe mode. Tap "+", swipe your finger on the phone screen, and the device will vibrate with the change of the swipe. You can keep the vibration mode for next use

mode or slide the operation interface of the APP to enter the shake mode, and the device will vibrate according to the shaking rhythm and amplitude of your Data is empty, please add it first

4. Shake mode: Click on the shake

j. After the interactive connection is

by default. You must first invite the

agrees to open the video function

Note: When interacting, the control

button is to control the other party's

before opening both parties.

device, not your own device.

successful, the video is not turned on

other party's video and the other party

5. Interactive mode: mode friend interface. c. Add friends Shake your cell phone

a. Tap the interactive mode or slide the operation interface of the APP to enter the interactive mode friend interface. b. Click the interactive button on the APP homepage to enter the interactive d. On the friend interface, click the friend button at the bottom and the friend search box will appear. Dear, you have not added any friend

1. Please charge the product properly in a safe place. 2. Water-based lube is suggested as lubricant. Do not apply

massage oil or hand cream to the toy surface 3. Stop using the product, if you feel uncomfortable or you find it is

no longer smooth or has sharp edges. 4. Not recommended to use it below one meter in the water.

5. Please clean it before and after use with warm water and soap

recycle bin for disposal.

FC (FOHS 4 X



will stop vibrating and enter the

stop flashing

standby state, and the APP icon will

mobile phone number, and mailbox. f. After the search results are displayed, you click the add button on

e. Friends search can search for

corresponding registered users by

gender and age, and can also search

accurately by ID number, nickname,

the right, and the system will send the friend request information to the target

g. After the other party receives the message of the friend application, click the message button to enter the message center to view the message (the red dot means: unread), agree or reject the other party's friend application, if agreed, the mutual friend addition is successful.

I. Click the icon of the friend you want to interact with, the system will initiate an interactive invitation, if the other party accepts your invitation, the interactive connection is successful. Note: If the other party is not connected to the toy, your interactive interface has no control buttons at this time. The toy must be connected to the other party to have control buttons on your interactive interface. The device connection button on this interface is the Bluetooth icon in the upper right

h. After the friend is successfully

the friend.

added, long press the friend icon to

comment, delete, black out, and report

Invites"lovely"to interact? Cancel Confirm

Control the opposite device

ease enter what you want to say

(boiling water NOT allowed), or sometimes with detergent, disinfectant or 75% alcohol.

6. Keep it in cool and dry place. Avoid direct sunlight.

7. Keep it out of reach of children.

8. The product contains lithium battery. Please put it in the non-

MADE IN CHINA



