

PODKŁADKA CHŁODZĄCA GCP600

Instrukcja obsługi
i warunki gwarancji

GCP600
COOLING PAD

Operating Manual
& Warranty Terms

WARUNKI BEZPIECZEŃSTWA I ZAGROŻENIA

1. Urządzenia należy używać wyłącznie w przypadku, kiedy urządzenie oraz przewód zasilający są w pełni sprawne i nie noszą śladów uszkodzeń.
2. Urządzenie należy podłączać i użytkować wyłącznie w sposób opisany w niniejszej instrukcji oraz zgodny z danymi uwzględnionymi na tabliczce znamionowej.
3. Niniejszy sprzęt może być użytkowany przez dzieci w wieku co najmniej 8 lat i przez osoby
4. Urządzenie oraz przewód zasilający nie mogą znajdować się w zasięgu dzieci poniżej ósmego roku życia.
5. Urządzenie można podłączać jedynie do portów USB w laptopie.
6. Ze względów bezpieczeństwa, do wszelkich napraw urządzenia uprawniony jest jedynie producent, serwis autoryzowany przez producenta lub osoba o odpowiednich kwalifikacjach.
7. Przewodu zasilającego oraz urządzenia nie należy dotykać gorącymi narzędziami.
8. Nie należy umieszczać urządzenia na niestabilnych lub gorących powierzchniach, ani w ich pobliżu.
9. Urządzenia nie należy zanurzać w wodzie lub innych cieczach,

ani używać w pobliżu umywalk, wanien i innych zbiorników napełnionych wodą.

WPROWADZENIE

Dziękujemy za zaufanie, jakim nas Państwo obdarzyli, dokonując zakupu urządzenia marki **MAD DOG**.

Jesteśmy przekonani, że to bardzo dobrej jakości urządzenie zapewni Państwu dużo radości i satysfakcji z jego użytkowania.

NALEŻY DOKŁADNIE PRZECZYTAĆ INSTRUKCJĘ OBSŁUGI I JEJ PRZESTRZEGAĆ!

To urządzenie jest przeznaczone do użytku domowego lub podobnego, nie dotyczącego celów komercyjnych.

Producent nie ponosi odpowiedzialności za szkody powstałe w wyniku użytkowania niewłaściwego lub niezgodnego z przeznaczeniem.

OPIS URZĄDZENIA

Podkładka chłodząca to urządzenie, dzięki któremu zyskujemy dobre chłodzenie laptopa. Podkładka zasilana jest poprzez podłączenie jej do laptopa za pomocą kabla USB. Chłodzenie zapewnia dłuższą żywotność baterii oraz stabilną pracę notebooków. Urządzenie współpracuje z laptopami do 17,3".

1. Regulowany kąt odchylenia (5 pozycji).
2. Dwa porty USB.
3. Wentylator chłodzący.
4. Blokady zabezpieczające urządzenie przed zsunieniem.

4

BEZPIECZEŃSTWO UŻYTKOWANIA

Należy zapoznać się z podanymi poniżej wskazówkami.

Nieprzestrzeganie tych wskazówek może być niebezpieczne lub niezgodne z prawem.

1. Urządzenie posiada niewymienne diody LED.
2. Długotrwałe wpatrywanie się w światło emitowane przez diody może doprowadzić do uszkodzenia wzroku.
3. Urządzenie nie jest wodoodporne. Chroń je przed wilgocią.
4. Urządzenie nie jest zabawką, należy przechowywać je z dala od dzieci.
5. Urządzenie należy czyścić suchą szmatką po uprzednim odłączeniu go od zasilania.


PODŁĄCZANIE URZĄDZENIA DO LAPTOPA

1. Urządzenie należy wyciągnąć z opakowania i ustawić metalową siatkę do góry.
2. Umieścić na podkładce chłodzącej laptop.
3. Podłączyć urządzenie wtykiem USB A do portu USB laptopa oraz portu USB podkładki.
4. Zmieniając pozycję nóżek podkładki, można zmienić kąt nachylenia i pozycję laptopa.

EKOLOGICZNA I PRZYJAZNA DLA ŚRODOWISKA UTYLIZACJA

To urządzenie jest oznaczone, zgodnie z Dyrektywą Parlamentu Europejskiego i Rady 2012/19/UE z dnia 4 lipca 2012 r. w sprawie zużytego sprzętu elektrycznego i elektronicznego (WEEE), symbolem przekreślonego kontenera na odpady:

5. Panel sterowania (zmiana podświetlenia; zmiana prędkości pracy wentylatora „-“ i „+”; włącz/wyłącz).
6. Podświetlenie RGB.



Aby włączyć/wyłączyć wentylator przytrzymaj przycisk włącz/wyłącz na panelu sterowania przez około 2 sekundy.

Aby włączyć/wyłączyć podświetlenie przytrzymaj przycisk zmiany podświetlenia na panelu sterowania przez około 2 sekundy.

DANE TECHNICZNE

Model	GCP600
Napięcie	5.0V --- 0.38A
Wymiar podkładki	400*290*40mm
Liczba portów USB	2
Wymiary wentylatora	170 x 170 x 20
Obroty wentylatora	800 rpm (+/-15%)

5



Nie należy wyrzucać urządzeń oznaczonych tym symbolem, razem z odpadami domowymi.

Urządzenie należy zwrócić do lokalnego punktu przetwarzania i utylizacji odpadów lub skontaktować się z władzami miejskimi.

MOŻESZ POMÓC CHRONIĆ ŚRODOWISKO!

Właściwe postępowanie ze użytym sprzętem elektrycznym i elektronicznym przyczynia się do uniknięcia szkodliwych dla zdrowia ludzi i środowiska naturalnego konsekwencji, wynikających z obecności składników niebezpiecznych oraz niewłaściwego składowania i przetwarzania takiego sprzętu.

WARUNKI GWARANCJI DLA PODKŁADKI CHŁODZĄCEJ

1. ART-DOM Sp. z o.o. z siedzibą w Łodzi (92-402) przy ul. Zakładowej 90/92 Numer Krajowego Rejestru Sądowego 0000354059 (Gwarant) gwarantuje, że zakupione urządzenie jest wolne od wad fizycznych. Gwarancja obejmuje tylko wady wynikające z przyczyn tkwiących w rzeczy sprzedanej (wady fabryczne).
2. Ujawniona wada zostanie usunięta na koszt Gwaranta w ciągu 14 dni od daty zgłoszenia uszkodzenia do serwisu autoryzowanego lub punktu sprzedaży.
3. W wyjątkowych przypadkach, np. konieczności sprowadzenia części zamiennych od producenta, termin naprawy może zostać wydłużony do 30 dni.
4. Okres gwarancji dla użytkownika wynosi 24 miesiące od daty wydania towaru.

5. Towar przeznaczony jest do używania wyłącznie w warunkach indywidualnego gospodarstwa domowego.
6. Gwarancja nie obejmuje:
 - a. uszkodzeń powstałych na skutek używania urządzenia niezgodnie z instrukcją obsługi,
 - b. uszkodzeń mechanicznych, chemicznych lub termicznych,
 - c. napraw i modyfikacji dokonanych przez firmy lub osoby nieposiadające autoryzacji producenta,
 - d. części z natury łatwo zużywalnych lub materiałów eksploatacyjnych takich jak: baterie, żarówki, bezpieczniki, filtry, pokrętła, półki, akcesoria,
 - e. instalacji, konserwacji, przeglądów, czyszczenia, odblokowania, usunięcia zanieczyszczeń oraz instruktażu.
7. O sposobie usunięcia wady decyduje Gwarant. Usunięcie potwierdzonej wady urządzenia nastąpi poprzez wykonanie naprawy gwarancyjnej lub wymianę urządzenia. Gwarant może dokonać naprawy, gdy kupujący żąda wymiany lub Gwarant może dokonać wymiany, gdy kupujący żąda naprawy, jeżeli doprowadzenie do zgodności towaru (urządzenia) zgodnie z udzieloną gwarancją w sposób wybrany przez kupującego jest niemożliwe albo wymagałoby nadmiernych kosztów dla Gwaranta. W szczególnie uzasadnionych wypadkach, jeżeli naprawa i wymiana są niemożliwe lub wymagałyby nadmiernych kosztów dla Gwaranta może on odmówić doprowadzenia towaru do zgodności z udzieloną gwarancją i zaproponować inny sposób załatwienia reklamacji z gwarancji.
8. Wymiany towaru dokonuje punkt sprzedaży, w którym towar został zakupiony (wymiana lub zwrot gotówki) lub autoryzowany punkt serwisowy, jeżeli dysponuje taką możliwością (wymiana). Zwracane urządzenie musi być kompletne, bez uszkodzeń mechanicznych. Niespełnienie tych warunków może spowodować nieuznanie gwarancji.
9. W przypadku braku zgodności towaru z umową sprzedaży, kupującemu z mocy prawa przysługują środki ochrony prawnej ze strony i na koszt sprzedawcy, a gwarancja nie ma wpływu na te środki ochrony prawnej.
10. Niniejsza gwarancja obowiązuje na terytorium Polski.
11. Warunkiem dokonania naprawy lub wymiany urządzenia w ramach gwarancji jest przedstawienie dowodu zakupu oraz użytkowanie towaru zgodnie z informacjami zawartymi w instrukcji obsługi.

UWAGA: Uszkodzenie lub usunięcie tabliczki znamionowej z urządzenia może spowodować nieuznanie gwarancji.

Cały czas udoskonalamy nasze produkty, dlatego mogą się one nieznacznie różnić od zdjęcia przedstawionego na opakowaniu. Przed przystąpieniem do użytkowania urządzenia przeczytaj instrukcję obsługi.

**ART-DOM Sp. z o.o., ul. Zakładowa 90/92, 92-402 Łódź,
info@artdom.net.pl. Numer Krajowego Rejestru Sądowego
0000354059.**



v.2

HAZARD CONDITIONS

1. The device should be used only if the device and the power cord are fully operational and do not demonstrate signs of damage.
2. Connect and use the device exclusively as described in this manual and in accordance with the data included in the name plate.
3. This device may be used by children aged at least 8 years and by persons with reduced physical and mental capabilities and a person lacking of knowledge and experience, if supervision

is provided or instructions for using the device in a safe manner so that the associated risks are understood. Children should not play with the device. Children without supervision should not carry out the cleaning and maintenance of the device.

4. The device and the power cord must remain out of reach of children under eight.
5. The device can only be connected to USB ports in laptops.
6. For safety reasons, only the manufacturer, service authorized by the manufacturer or a person with appropriate qualifications is

authorized to perform any repairs of the device.

7. Do not touch the power cord and the device with hot tools.
8. Do not place the device or its equipment on or near unstable or hot surfaces.
9. The device should not be immersed in water or other liquids, do not use it near wash-basins, baths and other water-filled reservoirs.

INTRODUCTION

Thank you for the trust you have placed in us when you purchased your **MAD DOG** device.

We are convinced that it is a high quality device and You'll have a lot of joy and satisfaction with its use.

PLEASE CAREFULLY READ AND FOLLOW THE OPERATING MANUAL!

12

TECHNICAL DATA

Model	GCP600
Voltage	5.0V ~ 0.38A
Pad dimensions	400*290*40mm
Number of USB ports	2
Fan Dimensions	170 x 170 x 20
Fan speed	800 rpm (+/-15%)

SAFETY OF USE

Please refer to the instructions below. Failure to follow these instructions can be dangerous or illegal.

1. The device has non-replaceable LEDs.
2. Prolonged staring at the light emitted by the diodes can lead to eye damage.
3. The device is not waterproof. Protect it from moisture.
4. The device is not a toy, please keep it away from children's reach.
5. Once disconnected from power the device can be cleaned with use of a dry cloth.

CONNECTING THE DEVICE TO A LAPTOP

1. Remove the device from the package and place so as the metal mesh points up.
2. Place the laptop on the cooling pad.
3. Connect the device with USB A plug to the USB port of the laptop and the USB port of the pad.

14


This device is intended for domestic or similar, non-commercial use.

The manufacturer will not be held liable for damages resulting from improper or non-compliant use.

DESCRIPTION

The cooling pad is a device that enables you to improve laptop cooling. The pad is powered by connecting it to the laptop using a USB cable. Cooling ensures longer battery life and more stable notebook operation. The device works with laptops up to 17.3".

1. Adjustable angle (5 positions).
2. Two USB ports.
3. Cooling fan.
4. Holders to prevent the device from slipping off.
5. Control panel (backlight change; "-" and "+" fan speed adjustment; on/off).
6. RGB backlight.



To turn the fan on/off, hold the on/off button on the control panel for about 2 seconds.

To turn the backlight on/off, hold down the backlight change button on the control panel for about 2 seconds.

13

4. By changing the position of the pad feet, you can change the angle of inclination and the position of the laptop.

ECO-FRIENDLY AND ENVIRONMENTALLY FRIENDLY DISPOSAL

This device is marked, in accordance with Directive 2012/19/EU of the European Parliament and of the Council of 4 July 2012 on waste electrical and electronic equipment (WEEE), with the symbol of a crossed-out waste container:



Do not dispose of the device marked with this symbol together with household waste.

For disposal return the device to your local waste treatment and disposal facility or contact your local authorities.

YOU CAN HELP PROTECT THE ENVIRONMENT!

Właściwe postępowanie ze zużytym sprzętem elektrycznym i elekProper handling of waste electrical and electronic equipment contributes to avoiding harmful consequences for human health and the environment resulting from the presence of hazardous components and improper storage and processing of such equipment.

WARRANTY CONDITIONS FOR THE COOLING PAD

1. ART-DOM Sp. z o.o. with its registered office in Łódź (92-402) at ul. Zakładowa 90/92 National Court Register Number 0000354059 (Guarantor) guarantees that the purchased device is free from physical

15

defects. The warranty covers only defects resulting from the causes inherent in the item sold (manufacturing defects).

2. A disclosed defect will be removed at the Guarantor's expense within 14 days from the date of reporting the damage to the authorized service or point of sale.
3. In exceptional cases, e.g. the need to import spare parts from their manufacturer, the repair period may be extended up to 30 days.
4. The warranty period for the user is 24 months from the date of delivery of the goods.
5. The goods are intended for use only in the conditions of an individual household.
6. The present warranty does not cover:
 - a. damage caused by using the device in a manner inconsistent with the user manual,
 - b. mechanical, chemical or thermal damage,
 - c. repairs and modifications made by companies or persons that were not authorized to do so by the manufacturer,
 - d. parts that are easy to use or consumables such as: batteries, bulbs, fuses, filters, knobs, shelves, accessories,
 - e. installation, maintenance, inspection, cleaning, unlocking, removal of contaminants and instruction.
7. The Guarantor will select the mode of defect removal at its own discretion. Removal of a confirmed defect of the device will take place through warranty repair or replacement of the device. The Guarantor may perform repairs when the buyer requests replacement or the Guarantor may perform replacements when the buyer requests repair, if bringing the goods (device) into conformity in accordance with the granted warranty in the manner selected by the buyer is impossible or would require excessive costs at the part of Guarantor. In particularly justified cases, if both repair and replacement are impossible or would

require excessive costs for the Guarantor, the Guarantor may refuse to bring the goods into compliance with the granted warranty and propose another way to settle the warranty claim.

8. The exchange of goods is made at the point of sale at which the goods were purchased (replacement or refund) or an authorized service point, if it offers such service (replacement). The returned device must be complete, without mechanical damage. Failure to comply with these conditions may result in failure to accept the warranty claim.
9. In the event of non-compliance of the goods with the sales contract, the buyer is entitled by law to legal protection measures on the part and at the expense of the seller, and the warranty does not affect these legal protection measures.
10. The warranty is valid in Poland.
11. The condition for the warranty repair or replacement of the device is the presentation of proof of purchase and the use of the goods in accordance with the information contained in the user manual.

CAUTION!

Damage or removal of the rating plate from the device may result in warranty being deemed void.

We are constantly improving our products, so they may differ slightly from the images presented on the packaging and in the user manual. Please read the user manual carefully before operating the device.

**ART-DOM Sp. z o.o., ul. Zakładowa 90/92, 92-402 Łódź,
info@artdom.net.pl. National Court Register number
0000354059.**



v. 4