Choose the correct adapters to connect with your faucet



Aerator can be removed



Aerator can not be removed



External Diameter: 15-21mm Downward length: >20mm



*Please feel free to contact us if neither adapters fit.