



















DC-30-72



30 min







	DŁUGOŚĆ LENGTH LONGUEUR	SZEROKOŚĆ WIDTH BREITE LARGEUR	GRUBOŚĆ THICKNESS STÄRKE GROSSEUR	IŁOŚĆ QUANTITY ANZAHL QUANTITÉ	KOD CODE CODE CODE	PACZKA BOX SCHACHEL BOÏTE
1	720	508	18	1		
2	720	508	18	1		
3	263	100	18	1		
4	263	100	18	1		
5	263	504	18	1		
6	713	296	18	1		
7	715	281	3	1		

