

**1**

Handle is disengaged for storage  
Lift handle until it clicks in place to engage clutch..

**2**

Lift the handle until the tobacco chamber opens fully.

**3**

Evenly place tobacco in the chamber,  
**LIGHTLY** compress with your fingers.

**4**

Insert the cigarette tube fully onto the nozzle.

**5**

Pull the handle fully down to fill cigarette tube with tobacco.

**6**

To disengage handle to store machine;  
pull at pivot to the right.