

TELESIN

User Guide / 使用说明

1.3M

Selfie Stick Tripod with Remote Control

1.3M 长款 遥控 自拍杆

Adapter
转接座

Phone Clip
手机夹

Tripod
三脚架

Unlock button
解锁键

On/Off key
开关键

Indicator light
指示灯

Mode switch key
模式切换键

Photo/record button
拍照/录制键

How to use 遥控器使用方法

1 Remote Switch On/Off 遥控器开关机

long press the on/off button  for 3s, the remote switches on/off

* When the GoPro is paired and connected, the GoPro will be switched on and off when the remote control is switched on and off


长按 开关键  3s, 遥控器开机/关机

* 在配对连接GoPro状态下, 遥控器开关机时, GoPro也同步开关机

2 Connection 连接

1 Select pairing mode 选择配对模式

If it is GoPro pairing mode, the indicator light will turn green and flash; if it is phone pairing mode, the indicator light will turn red and flash

long press the mode key  for 3s to switch the pairing mode

长按 模式键  3s, 即可切换配对模式

若为GoPro配对模式, 指示灯绿色快闪; 若为手机配对模式, 指示灯红色快闪

2 Pairing connection 配对连接

To remotely control the gopro, open the remote in the gopro camera, and the pairing will be successful automatically, at which time the indicator light will change from fast flashing to slow flashing

To remotely control a smart phone, open the phone Bluetooth, search for TC-RCSS, click on the pairing connection, and the pairing will be successful, at which time the indicator will change from fast flashing to slow flashing

* If the remote control is not paired with any device within three minutes, the remote control will automatically shut down


若要遥控gopro, 在gopro相机里打开 the remote, 即可自动配对成功, 此时指示灯由快闪变慢闪

若要遥控手机, 打开手机蓝牙, 搜寻 TC-RCSS, 点击配对连接, 即可配对成功, 此时指示灯由快闪变慢闪

* 若遥控器三分钟内未配对连接任何设备, 遥控器自动关机

3 Photo/Recording 拍照/录制

In Gopro pairing mode, click the photo button  to start recording/photography; click the photo button  again to end recording/photography again. Click the mode switch key , the camera mode switches among the photo / time lapse / video

In the phone pairing mode, click the photo key  to take pictures; click the photo key  again to take pictures again; long press the photo key  for 2s to start recording; long press the photo key  again for 2s to end recording

4 Charging status is displayed 充电状态显示

when charging is in progress, the indicator shows a red light; when charging is complete, the indicator shows a green light

充电中, 指示灯显示红灯; 充电完成, 指示灯显示绿灯

Product Parameters 产品参数

Model: TE-RCSS-003

Brand: TELESIN

Size: 48x32x245mm

Weight: 320g

型号: TE-RCSS-003

品牌: TELESIN

尺寸: 48x32x245mm

重量: 320g

Packing list: 1.3m selfie stick, remote control, phone clip, long screw, data cable

包装清单: 1.3米自拍杆、遥控器、手机夹、长螺杆、数据线

Remote control 遥控器

Voltage: 3.7V/40mAh 0.148Wh

Input: USB-C: 5V=100mA,0.5W Max

Operating temperature: 0~45°C

Use time: approximately 5H

Charging time: about 1H

电压: 3.7V/40mAh 0.148Wh

输入: USB-C: 5V=100mA,0.5W Max

工作温度: 0~45°C

使用时长: 约5H

充电时长: 约1H

Disclaimer 免责声明

Please read this statement carefully and by using this product you will be deemed to have acknowledged and accepted it in full. Please check the product carefully before each use and do not use it if damaged or deformed. By using this product, you acknowledge and agree that you are fully responsible for your actions and the possible consequences of using this product.You undertake to use this product only for legitimate and lawful purposes. You understand and agree that ("Telesin") shall not be liable for any misuse, adverse effects, damages, injuries, penalties or other legal consequences arising directly or indirectly from the use of this product. The user should follow the precautions including but not limited to those mentioned herein. To the extent Telesin reserves the right to interpret and modify this commitment within the limits of national laws and regulations.

/ 请仔细阅读本声明, 一旦使用本产品, 即视为对本声明的全部认可和接受。每次使用前, 请仔细检查产品, 若出现破损、变形, 请勿使用, 使用本产品, 就意味着您认可并同意, 您将对使用本产品的行为和可能产生的后果负全部责任。您承诺仅会出于正当合法的目的使用本产品。您理解并同意, 对于直接或间接使用本产品而造成的滥用、不利影响、损害、伤害、惩罚或者其他法律后果, 泰迅数码有限公司 (以下简称 "Telesin") 将不承担任何责任。用户应遵循包括但不限于本文提及的使用注意事项, 在国家法律法规范围内, 本承诺解释权、修改权归 Telesin 所有。

www.telesin.cn

图 纸 变 更 历 程	卡纸类生产检验标准						编号	物料名称			物料代码		材质		工艺		尺寸										
	1.包装盒尺寸允许误差范围±1mm						①	1.3米长款遥控自拍杆-说明书					300g单粉卡+哑膜 双面印刷				200x117mm										
	2.模切整齐, 无爆边, 无皱角, 爆角						②																				
	3.印刷清晰, 颜色准确, 无色系偏差, 无墨点, 脏污, 允许走位±1.5mm						③																				
	4.粘贴位齐平, 无残胶, 溢胶						④																				
卡纸类生产检验标准							名称	1.3米长款遥控自拍杆						尺寸			型号	TE-RCSS-003	日期	20220817							
							材质					表面处理				比例	1	版次	A/1	页次							