



Smartwatch damski DIAMOND LUSSO SWD01



INSTRUKCJA OBSŁUGI

PL KWESTIE BEZPIECZEŃSTWA


Producent nie ponosi odpowiedzialności za jakiegokolwiek uszkodzenia/urazy spowodowane niewłaściwym użytkowaniem urządzenia. Przed użyciem należy dokładnie zapoznać się z treścią niniejszej instrukcji obsługi i przechowywać ją w bezpiecznym miejscu.

Urządzenia nie wolno zanurzać w gorącej wodzie. Nie wolno pływać w urządzeniu. Zabrania się wrzucania urządzenia do ognia. Bateria może eksplodować, zagrażając życiu i zdrowiu. Aby uniknąć ryzyka porażenia prądem lub pożaru, nie należy trzymać urządzenia w miejscach o dużej wilgotności lub wysokiej temperaturze. To urządzenie może wpływać na działanie urządzeń medycznych w jego otoczeniu. Należy zachować ostrożność, gdy używa się go w pobliżu urządzeń medycznych elektronicznych, takich jak rozruszniki serca, aparaty słuchowe i inne. Nie należy wystawiać urządzenia na bezpośrednie i długotrwałe działanie ciepła ani promieni słonecznych. Dalsze użytkowanie urządzenia w przypadku jego uszkodzenia lub awarii jest niedozwolone. W przypadku powyższego należy skontaktować się z serwisem. Próby samodzielnej naprawy urządzenia skutkują utratą gwarancji oraz mogą prowadzić do jego stałego uszkodzenia. Do czyszczenia urządzenia należy używać tylko miękkiej ściereczki zwilżonej wodą. Nie należy stosować żadnych agresywnych środków czyszczących ani innych substancji czyszczących.

W zależności od danej partii produktu, wersji oprogramowania, funkcje opisane w niniejszej instrukcji mogą się nieco różnić od tych występujących w urządzeniu.

PL POBIERZ APLIKACJE

1. Zeskanuj powyższy kod QR, aby pobrać oraz zainstalować aplikację FitCloudPro na telefon.
2. Aplikację możesz też zainstalować wyszukując w Sklep Play lub AppStore: „FitCloudPro”



Aplikacja kompatybilna jest z urządzeniami pracującymi na platformie Android oraz iOS. Aplikacja niezbędna jest do korzystania z funkcji smartwatcha.

Przy pierwszym uruchomieniu aplikacji należy udzielić wymagane zgody oraz uprawnienia. W innym wypadku aplikacja nie będzie działać prawidłowo.

PL ŁADOWANIE URZĄDZENIA

1. Smartwatch jest ładowany za pomocą kabla magnetycznego dołączonego do zestawu.
2. Przyłóż magnetyczną końcówkę kabla ładującego tak, by została ona przyciągnięta do portu ładowania przez magnesy zainstalowane w obudowie urządzenia.
3. Następnie połącz drugi koniec kabla z portem USB komputera lub zasilacza USB.




Jeśli podłączenie jest poprawne, na ekranie zegarka zobaczysz animację ładowania. Jeśli nie widzisz animacji, sprawdź czy zegarek jest dobrze podłączony. Jeśli bateria jest zupełnie pusta animacja może się pokazać po kilku minutach.

Przed pierwszym uruchomieniem urządzenia zaleca się ładować je przez około 2 godziny.

Napięcie ładowania nie powinno przekraczać 5V. Zalecane natężenie ładowania to maksymalnie 1A.

PL PAROWANIE URZĄDZENIA

1. Uruchom Bluetooth w telefonie i otwórz aplikację [FitCloudPro]
2. Idź do środkowej zakładki [URZĄDZENIE] i naciśnij [DODAJ URZĄDZENIE]
3. Wybierz urządzenie z listy o nazwie [SWD01]
4. Urządzenie sparowane



Smartwatch Manta Diamond Lusso współpracuje ze smartfonami obsługującymi łączność Bluetooth 5.0. Jest także kompatybilny z systemem Android 4.4 (i nowsze), oraz systemem iOS 8.4 (i nowsze).

Podczas parowania pomocny może być adres MAC w zakładce [Ustawienia] — [System] - [Informacje o systemie]. Dzięki temu zidentyfikujesz swoje urządzenie na liście skanowanych urządzeń w aplikacji podczas parowania.

PL OBSŁUGA URZĄDZENIA

1. Przycisk funkcyjny(1): (włączanie/wstecz/wygaszanie ekranu/wybudzanie ekranu)
2. Zestaw czujników
3. Magnetyczny port ładowania



6

PL INTERFACE URZĄDZENIA

1. CENTRUM STEROWANIA
2. SZYBKE MENU
3. AKTYWNOŚĆ
4. POWIADOMIENIA



7

PL PODSTAWOWE FUNKCJE


1. KLAWIATURA
2. KONTAKTY
3. REJESTR POŁĄCZEŃ



8

PL PODSTAWOWE FUNKCJE


1. ASYSTENT GŁOSOWY
2. AKTYWNOŚĆ
3. TRENING



9

PL PODSTAWOWE FUNKCJE

1. CIŚNIENIE KRWI
2. TĘTNO
3. POGODA



10

PL PODSTAWOWE FUNKCJE

1. KALENDARZ CYKLU
2. MUZYKA
3. SEEN

11

PL PODSTAWOWE FUNKCJE

1. POZOSTAŁE FUNKCJE
2. STYŁ GŁÓWNEGO MENU
3. WYŚWIETLACZ
4. JASNOŚĆ
5. WYBÓR TARCZY
6. CZAS AKTYWNEGO EKRANU
7. CZAS SKRĘTU NADGARSTKA

12

PL PODSTAWOWE FUNKCJE

1. SPECYFIKACJA TECHNICZNA
2. WYŚWIETLACZ
3. WODOODPORNÓŚĆ
4. POJEMNOŚĆ AKUMULATORA
5. WAGA
6. WYMIARY KOPERTY
7. OBWÓD NADGARSTKA

13

PL PODSTAWOWE FUNKCJE

1. INSTRUKCJA W WERSJI ELEKTRONICZNEJ
2. ZESKANUJ PONIŻSZY KOD QR
3. ROHS
4. CE
5. MADE IN P.R.C.
6. FOR MANTA EUROPE
7. LUB WEJDŹ NA STRONĘ: software.manta.com.pl

14

PL PODSTAWOWE FUNKCJE

1. BATERIA
2. INTENSYWNOŚĆ WIBRACJI
3. JĘZYK
4. KOD QR
5. ALARM
6. ZNAJDZ TELEFON
7. USTAWIENIA

15

PL PODSTAWOWE FUNKCJE

1. SPECYFIKACJA TECHNICZNA
2. WYŚWIETLACZ
3. WODOODPORNÓŚĆ
4. POJEMNOŚĆ AKUMULATORA
5. WAGA
6. WYMIARY KOPERTY
7. OBWÓD NADGARSTKA

16



Women's smartwatch DIAMOND LUSO SWD01



USER MANUAL

EN SAFETY ISSUES


The manufacturer is not responsible for any damage/injury caused by improper use of the device. Please read this manual carefully before use and keep it in a safe place.

The device can't be submerged in hot water. Do not swim in the device. It is forbidden to throw the device into fire. The battery may explode, threatening life and limb. To avoid the risk of electric shock or fire, do not keep the device in places with high humidity or high temperature. This device may affect the operation of medical devices in its environment. Be careful when using it near electronic medical devices such as pacemakers, hearing aids, and more. Do not expose the device to direct and prolonged exposure to heat or sunlight. Further use of the device in the event of its damage or failure is not allowed. In the case of the above, please contact the service. Attempts to repair the device yourself will void the warranty and may lead to its permanent damage. Only use a soft cloth dampened with water to clean the device. Do not use any aggressive cleaning agents or other cleaning substances.

Depending on the product batch, software version, the functions described in this manual may differ slightly from those in the device.

EN DOWNLOAD APP

1. Scan the QR code above to download and install the FitCloudPro app on your phone.
2. You can also install the application by searching the Play Store or AppStore: "FitCloudPro"




The application is compatible with devices operating on the Android and iOS platforms. The application is necessary to use the smartwatch function.

When you start the application for the first time, you must grant the required consents and permissions. Otherwise, the application will not work properly.

EN CHARGING

1. The smartwatch is charged using the magnetic cable included in the kit.
2. Place the magnetic end of the charging cable so that it is attracted to the charging port by the magnets installed in the housing of the device.
3. Then connect the other end of the cable to a USB port on your computer or USB power adapter.



If the connection is correct, you will see a charging animation on the watch screen. If you don't see the animation, check if your watch is properly connected. If the battery is completely empty, it may take a few minutes for the animation to show up.

Before using the device for the first time, it is recommended to charge it for about 2 hours.


The charging voltage should not exceed 5V. The recommended charging current is a maximum of 1A.

EN PRODUCT DESCRIPTION




1. Function button(1): (Power on/back/screen blank/ wake screen)
2. Sensor set
3. Magnetic charging port

EN INTERFACE



EN PAIRING



The Manta Diamond Luso smartwatch works with smartphones that support Bluetooth 5.0 connectivity. It is also compatible with Android 4.4 (and newer) and iOS 8.4 (and newer).

During pairing, the MAC address in the [Settings] - [About] - [System Info] tab may be helpful. Thanks to this, you will identify your device in the list of scanned devices in the application during pairing.

EN BASIC FUNCTIONS

TELEPHONE
Once you connect your smartwatch to your phone, you can use your watch to dial numbers to make and receive phone calls. You must maintain a connection between your watch and phone for the feature to work properly.

CONTACT
From the FitCloudPro application, you can add your favorite contacts to be able to make a phone call to selected numbers from the smartwatch.

CALL RECORDS
With the correct connection of the smartwatch to the phone, you can also view the watch's phone call history.

EN BASIC FUNCTIONS

VOICE ASSISTANT
With the correct connection of the smartwatch with the phone, the device can wake up the voice assistant on the phone.

The function is available in the main menu of the smartwatch and in the quick menu.

DATA
In the [DATA] function, the device provides the user with data from the whole day of activity, such as: total steps, total calories burned and distance.

WORKOUT
Select one of the many sport modes in the [TRAINING] function and activate them with one click. During training, the function will provide data such as time, total steps, total calories burned, heart rate, distance and pace on the screen.

NOTE: Not all sport modes record the above-mentioned data.

EN BASIC FUNCTIONS

WORKOUT RECORDS
After training, its results will be available for viewing in the [WORKOUT RECORDS] function from the smartwatch and in the FitCloudPro application.

HEART RATE
Thanks to the built-in sensors, the smartwatch can monitor your heart rate throughout the day. You can also start the heart rate measurement manually by activating the functions by clicking on the function.

SLEEP
If you wear the device while sleeping, the [SLEEP] function allows the user to view hours, statistics and sleep quality from the smartwatch or in the FitCloudPro app.

NOTE: The sleep statistics on the smartwatch are reset to zero after 24 hours.

EN BASIC FUNCTIONS

CYCLE CALENDAR
For female users, the smartwatch has the [CYCLE CALENDAR] function, which, when configured in the FitCloudPro application, allows you to monitor the menstrual cycle. After configuration, the device informs the user about the upcoming menstruation, fertile days and ovulation in the form of notifications.

MUSIC
After properly connecting the device with the FitCloudPro application, you can remotely control the music player on your phone from the smartwatch.

WEATHER
[WEATHER] function It can display the weather information for the current and next 7 days.

NOTE: Weather information is synced when connected to the FitCloudPro app. The data will not be updated after a long disconnection.

EN OTHER FUNCTIONS

Stopwatch: Timing function with mark function laps.

Timer: Timing function with marking function "Rounds" (laps).

Alarm clock: This function allows you to display the set alarms vibration sensors from the FitCloudPro app.

Find phone: Smartphone search function. It triggers the signal beep or vibrate on your phone.

Settings:

- **Menu style:** Main menu style change function smartwatch menu. There are 4 display styles to choose from main functions
- **Display:** Dividing display configuration function to individual functions:

Watch face switch: Smartwatch face change function. There are 7 different dials to choose from.

Brightness: Screen brightness setting function.

Screen time: Time setting function active screen from 5 s to 30 s.

Raise to wake: Time setting function reaction to waking up the smartwatch screen with a hand movement.

TECHNICAL SPECIFICATIONS

Display: 1,32" 360x360 px

Waterproof: IP67

Battery capacity: 230 mAh


Weight: 55 g

Case dimensions: 43 x 43 x 9 mm

Wrist circumference: 10 - 22 cm

USER MANUAL IN ELECTRONIC VERSION

Scan the QR code below to download the always up-to-date electronic manual (other languages also available):



Or go to the website:
software.manta.com.pl

RoHS **CE** **WEEE**

Made in P.R.C.
FOR MANTA EUROPE

The device is marked with the symbol of a crossed-out garbage container, in accordance with the European Directive 2012/19/EU on waste electrical and electronic equipment (WEEE). Products marked with this symbol should not be recycled or disposed of with other household waste at the end of their useful life. The user is obliged to dispose of waste electrical and electronic equipment by delivering it to a designated point where such hazardous waste is subject to the recycling process. The collection of this type of waste in separate places and the proper process of its recovery contributes to the protection of natural resources. Proper recycling of waste electrical and electronic equipment has a beneficial effect on human health and the environment. For information on where and how to dispose of waste electrical and electronic equipment in an environmentally safe manner, the user should contact the appropriate local authority, the waste collection point or the point of sale where the equipment was purchased.

Warning!
Product design and specifications are subject to change without prior notice. This applies primarily to technical parameters, software, photos and the user manual. This user's manual is intended as a general guide to operating the product. The manufacturer and distributor do not bear any liability for compensation for any inaccuracies resulting from errors in the descriptions in the user manual.

Manta S.A. hereby declares that the devices SWD01GB and SWD01BK complies with the RED Directive 2014/53/EU. The full text of the declaration of conformity is available at www.manta.com.pl