

INSTRUKCJA WÓZKA PLAŻOWEGO MAGNUM

Przed rozpoczęciem użytkowania przeczytaj niniejszą instrukcję, zachowaj ją, ponieważ może przydać się w przyszłości. Elementy opakowania trzymać z dala od dzieci, ryzyko uduszenia. Przed rozpoczęciem użytkowania upewnij się, że żaden z elementów wózka nie jest uszkodzony.

CZYSZCZENIE I KONSERWACJA:

- Wózek należy czyścić wilgotną szmatką,
- W razie większych zabrudzeń można umyć wózek za pomocą płynu do mycia naczyń, następnie wysuszyć,
- Nie należy czyścić wózka ostrymi narzędziami oraz silnymi detergentami,
- Po użyciu wózka na plaży zaleca się oczyścić go z piasku i brudu,
- Elementy metalowe należy zabezpieczyć przed korozją odpowiednimi do tego środkami,
- Po zakończeniu sezonu letniego wózek należy dokładnie wyczyścić i wysuszyć,
- Gdy nie używasz wózka przechowuj go w chłodnym, zacienionym miejscu,
- Unikaj nadmiernych zabrudzeń.

UŻYTKOWANIE:

- Wózek należy używać zgodnie z jego przeznaczeniem,
- Nie należy przeciążać wózka, maksymalne obciążenie to 80 kg,
- Nie należy skakać ani uwieszać się na wózku,
- W wózku nie należy przewozić dzieci ani zwierząt,
- Produkt nie jest zabawką,
- Nie pozwalać dzieciom używać wózka bez nadzoru osoby dorosłej,
- Nie używać wózka gdy jest uszkodzony,
- Uszkodzone elementy należy bezzwłocznie naprawić,
- Wózek należy chronić przed nadmiernym słońcem, które może powodować blaknięcie materiału,
- Należy chronić przed silnym wiatrem, gradem i deszczem.
- Nie używać wózka na powierzchniach/terenach które mogą spowodować uszkodzenia kół,
- Nie przewozić w wózku przedmiotów, które mogą trwale uszkodzić wózek.

INSTRUCTION BEACH STROLLER MAGNUM

Before use, read this manual and keep it as it may be useful in the future. Keep packaging components away from children
- risk of suffocation. Before using it, make sure that all parts of the stroller are not damaged.





CLEANING AND MAINTENANCE:

- The stroller should be cleaned with a damp cloth,
- If there is more dirt, you can wash the stroller with dishwashing liquid and then dry it,
- Do not clean the stroller with sharp tools or strong detergents,
- After using the stroller on the beach, it is recommended to clean it of sand and dirt,
- Metal elements should be protected against corrosion with appropriate means,
- After the end of the summer season, the stroller should be thoroughly cleaned and dried,
- When you are not using the stroller, store it in a cool, shaded place.- Avoid excessive dirt.





USE:

- The stroller must be used for its intended purpose,
- Do not overload the stroller, maximum load is 80 kg,
- Do not jump or hang on the stroller,
- Do not transport children or animals in the stroller,
- The product is not a toy,
- Do not allow children to use the stroller without adult supervision,
- Do not use the stroller if it is damaged,
- Damaged elements must be repaired immediately,
- The stroller should be protected from excessive sunlight, which may cause the material to fade,
- Protect against strong wind, hail and rain.
- Do not use the stroller on surfaces/areas that may cause damage to the wheels,
- Do not transport items in the stroller that may permanently damage the stroller.

WYKAZ CZĘŚCI/ PART LIST

A  1X	C  4X	E  4X	G  2X
B  1X	D  1X	F  4X	

INSTRUKCJA SKŁADANIA/ ASSEMBLY INSTRUCTIONS



Producent/Producer:
GRUPA-MG Mikołaj Gockowiak
Ciele, ul. Niedźwiedzia 11
86-005 Białe Błota