

# Function Key Combination Description




Switch the direction of the backlight dynamic effect;



Cycle through backlight effect mode



7 kinds of backlight effects cycle adjustment



1,2,3 .... 0,-, = switch to F1, F2, F3, ... F10,F11,F12



Implements the transcoding function

[ { ↔ PS ] ↔ PB K ↔ INS L ↔ HOME :: ↔ PU  
“ ” ↔ PD , < ↔ DEL . > ↔ END



Implements the transcoding function

/ ? ↔ ↑ Alt M3 ↔ ← E M2 ↔ ↓ Ctrl M1 ↔ →




Implements the transcoding function

W ↔ ↑ A ↔ ← S ↔ ↓ D ↔ →



On / Off  
Lock WIN function



Restore  
Factory settings