

140x100mm

140x100mm

正面

Wskaźnik wymiany baterii

- Jeżeli na wyświetlaczu pojawi się symbol "Lo", należy wymienić baterie w urządzeniu.



Aby wymienić baterie, należy otworzyć zaślepkę z tyłu urządzenia, a następnie wymienić baterie. Nie wolno zginać styków. Unikać kontaktu baterii z ogniem. Zużyte baterie ze względu na zawarte w nich szkodliwe substancje dla środowiska powinny być zgodnie z przepisami o utylizacji odpadów niebezpiecznych dostarczane do punktów zbiórki zużytych baterii.



Pierwsiaki oraz związki chemiczne zawarte w urządzeniu mogą mieć negatywny wpływ na środowisko naturalne i zdrowie ludzkie. Zużyty sprzęt elektryczny oraz elektroniczny oznaczony symbolem przekreślonego kosza nie może być umieszczany w pojemnikach na odpady komunalne. Tak sprzęt podlega zbiórce i recyklingowi. Obowiązki wynikające z ustawy o zużytych sprzęcie elektrycznym i elektronicznym w imieniu przedsiębiorcy, zgodnie z odpowiednią umową, przejęła Organizacja Odkrysu.



Wyprodukowano w ChRL dla Lamex
Lipówki, ul. Radosna 10
08-440 Piława



Waga łazienkowa LTC **LXWG105, LXWG106**

Aby zapewnić prawidłowe działanie oraz prawidłową konserwację urządzenia, należy uważnie przeczytać niniejszą instrukcję.

Specyfikacja

- System czujników tensometrycznych o wysokiej precyzji.
- Bezpieczny podest z hartowanego szkła.
- Maksymalne obciążenie: 180kg
- Dokładność pomiaru: do 100g
- Automatyczne zerowanie oraz wyłączanie urządzenia przy dłuższym okresie braku użytkowania
- Wskaźnik niskiego zasilania oraz przeciążenia
- Przycisk UNIT do zmiany jednostek wagi - kg / lb / stone (przycisk jest z tyłu urządzenia, przy komorze baterii, podpisany SET/UNIT).

140x100mm

140x100mm

反面

Zasilanie

- Baterie 2x AAA 1,5V. Przed użyciem należy usunąć izolację zabezpieczającą baterie. Baterie należy wymienić na nowe przy niskim stanie napięcia.

Uwagi

- Urządzenie należy używać na twardej, płaskiej powierzchni. Nierówne powierzchnie mogą wywołać niebezpieczeństwo i wpłynąć na wynik pomiaru.
- Nie wolno używać wagi jeśli szklany podest jest pęknięty lub w jakikolwiek sposób uszkodzony!
- Urządzenie zaokrągla wynik ważenia do 100g.
- Urządzenie należy czyścić suchą, miękką ściereczką. Unikaj kontaktu urządzenia z wodą. Nie należy używać środków czyszczących przy czyszczeniu urządzenia.
- Jeżeli urządzenie nie będzie używane przez dłuższy okres czasu, należy wyjąć z niego baterie.
- Wagę należy obsługiwać ostrożnie, aby jej nie rozregulować lub uszkodzić.
- Nie wolno upuszczać urządzenia ani skakać na podest.

Obsługa urządzenia

Krok 1. Umieść wagę na twardej, płaskiej powierzchni (unikaj dywanów lub innych, miękkich powierzchni).

Krok 2. Stań na wadze równomiernie i bez ruchu. Po około trzech sekundach urządzenie wyświetli wynik pomiaru.



Krok 3. Po zejściu z wagi, urządzenie wyłączy się samoczynnie.

Wskaźnik przeciążenia

Jeżeli urządzenie jest przeciążone (waga powyżej 180kg) wyświetli komunikat „Err”.



Uwaga

Powierzchnia wagi jest śliska gdy jest mokra!



140x100mm

140x100mm

正面

BATTERY CHANGE INDICATOR

When the batteries need replacing the following will appear on the screen:



Please open the back board of the scales, then take the batteries carefully out of the battery compartment. Please push the metal sheet outwards by your finger nails or a sharp instrument. The battery will pop up. Do not bend the contacts back while you do this, or they may break. Dispose of the old batteries in a safe place. Do not place on fire.



The elements and chemical compounds contained in the equipment may have a negative impact on the environment and human health. Used electric and electronic equipment marked with the crossed-out wheeled garbage can symbol may not be placed in municipal waste garbage cans. Such equipment is subject to collection and recycling. Responsibilities arising from the Waste Electrical and Electronic Equipment Act are taken over by Recovery Organization on behalf of the operator, pursuant to an appropriate agreement.



Made in P.R.C. for Lamex
Lipówki, ul. Radosna 10
08-440 Piława



**LTC Bathroom scale
LXWG105, LXWG106**

INSTRUCTIONS MANUAL

Your new electronic personal scales have been designed to accurately indicate your weight gain or loss over a period of time and should give you many years of service under normal use.

SPECIFICATIONS

- Equipped with a high precise strain gauge sensor system
- Tempered safety glass / platform
- Capacity:180kg (396lb/25 stone)
- Division: 100g (0.2Lb)
- Foot-tap switch
- Auto zero resetting & auto power off
- Low power & over-load indicator
- Press "unit" button to convert unit kg/ lb/ st. The "unit" button is on the backside of the scale (under the battery box whit "set/unit" index).

140x100mm

140x100mm

反面

POWER SUPPLY

- BATTERY (2*AAA)
Please remove the insulation sheet from the battery contacts before using. Replace the batteries when the "low battery indicator" shows.

CARE AND ATTENTION

- Placing your scales on a hard, flat surface will ensure the greatest accuracy and repeatability.
- Always weigh yourself on the same scales placed on the same floor surface, uneven floors may affect the readings.
- Your scales round up or down to the nearest 100g/0.2Lb
- Clean your scale with a damp cloth but do not allow water to get inside the scales. Do not use any chemical cleaning agents.
- Do not allow your scales to become saturated with water as this can damage the electronics.
Remove the batteries if the scales are not going to be used for a long period of time
- Treat your scales with care. It is a precision instrument, do not drop or jump up or down on them.
- Do not use the scale if the glass platform is cracked or damaged in any way!

OPERATING INSTRUCTIONS

- Step 1. Put the scales on a hard flat surface (avoiding carpets or any soft surfaces)
Step 2. Stand on the scale, put your feet evenly on the scale without moving, later after about three seconds your correct weight will be displayed as below picture shown:



- Step 3. When you step off the scale, it will automatically switch off.

OVERLOAD INDICATOR

When the scales are overloaded (over 180kg/396lb/25 stone),the following will appear on the screen:



CAUTION

Slippery when wet.

