



KONFIGURACJA

1. Podłącz opaskę do odpowiedniego zasilania (power bank / 5V2A).
2. Naciśnij i przytrzymaj przez ok 2-3s przełącznik kontroli temperatury, aby aktywować funkcję ogrzewania. Dioda powinna się zaświecić.
3. Opaska rozpoczyna grzanie w wysokim trybie i po osiągnięciu maksymalnej temperatury po ok 5 minutach, przechodzi do średniego trybu ogrzewania.
4. Ogrzewanie posiada 3 stopnie intensywności. Pojedyncze naciśnięcie przycisku spowoduje zmianę aktualnego trybu:
 - a. czerwona dioda - wysoka temperatura (ok 42-45°C)
 - b. biała dioda - średnia temperatura (ok 39-42°C)
 - c. niebieska dioda - niska temperatura (ok 36-39°C)
5. Naciśnij i przytrzymaj przez ok 2-3s przełącznik kontroli temperatury, aby wyłączyć funkcję ogrzewania. Dioda powinna zgasnąć.

CZYSZCZENIE, KONSERWACJA I DODATKOWE INFORMACJE

1. Odłącz i wyjmij zasilanie przed przystąpieniem do czyszczenia opaski.
2. Używaj delikatnych detergentów. Zalecane jest delikatne pranie ręczne. Pranie maszynowe jest dozwolone jedynie w niskiej temperaturze, w woreczku ochronnym i na niskich obrotach.
3. Zaleca się naturalne suszenie na powietrzu.
4. Zawsze upewnij się, że opaska jest całkowicie sucha przed jej ponownym użyciem. Nigdy nie podłączaj do zasilania mokrej opaski.
5. Jeżeli dojdzie do zamoczenia opaski, niezwłocznie wyłącz funkcję grzania i odłącz zasilanie.
6. Czas ogrzewania zależy od pojemności powerbanku oraz od ustawionego programu pracy. Przykładowo dla akumulatora 5000mAh czas pracy wyniesie ok 4h dla wysokiego, ok 5h dla średniego i ok 8h dla niskiego trybu grzania.
7. Trzymaj z dala od dzieci.
8. Nie ingeruj w konstrukcję urządzenia.



Instrukcję w innych wersjach językowych znajdziesz na naszej stronie internetowej.



CONFIGURATION

1. Connect the band to the appropriate power supply (power bank / 5V2A).
2. Press and hold the temperature control switch for about 2-3 seconds to activate the heating function. The diode should light up.
3. The band starts heating in high mode and after reaching the maximum temperature after about 5 minutes, it switches to medium heating mode.
4. The heating has 3 intensity levels. A single press of the button will change the current mode:
 - a. red diode - high temperature (approx. 42-45°C)
 - b. white diode - medium temperature (approx. 39-42°C)
 - c. blue diode - low temperature (approx. 36-39°C)
5. Press and hold the temperature control switch for about 2-3 seconds to turn off the heating function. The diode should turn off.

CLEANING, MAINTENANCE AND ADDITIONAL INFORMATION

1. Disconnect and unplug the power before cleaning the band.
2. Use mild detergents. Gentle hand washing is recommended. Machine washing is only allowed at low temperature, in a protective bag and at low speed.
3. Natural air drying is recommended.
4. Always make sure the band is completely dry before reusing it. Never connect a wet band to the power supply.
5. If the band gets wet, immediately turn off the heating function and unplug the power supply.
6. The heating time depends on the capacity of the power bank and the set work program. For example, for a 5000mAh battery, the working time will be about 4 hours for high, about 5 hours for medium and about 8 hours for low heating mode.
7. Keep away from children.
8. Do not tamper with the device's structure.



You can find instructions in other languages on our website.