




Instrukcja montażu/Montážní návod/Assembly instructions

- A  x11
- B  x11
- C  x2
- D  x4
- E  x2
- F  x2
- G  x4
- H  x6
- I  x2
- J  x8
- K  x8
- L  x4
- M  x1
- N  x3
- O  x1
-  x1


Cross screwdriver (not included)
Śrubokręt krzyżowy (nie wliczone)




Křížový šroubovák (není součástí dodávky)




3




4




5




6




7




9




8




10




11



12



4128



GB: Instructions for assembly
D: Aufbauanleitung
F: Instructions de montage
I: Istruzioni di montaggio
NL: Montagehandleiding
E: Instrucciones de montaje
P: Instruções de montagem
DK: Monteringsvejledning
S: Konstruktionsanvisning
FIN: Kokoamisohje
N: Veiledning for oppbygging
H: Felépítési utasítás
CZ: Návod pro sestavení
PL: Instrukcja montażu
GR: Οδηγίες συναρμολόγησης
RUS: Указания по сборке
TR: Kurulum kılavuzu
SI: Navodilo za postavitev
HRV: Uputa za sastavljanje
SK: Návod na montáž
BG: Инструкции за монтаж
RO: Instrucțiuni de montaj
UA: Вказівки зі встановлення
AR: تعليمات تجميع أجزاء اللعبة

GB: Must be assembled by an adult. **D:** Muss von Erwachsenen montiert werden. **F:** A monter par un adulte. **I:** Deve essere montato da un adulto. **NL:** Dient door volwassenen gemonteerd worden. **E:** Debe ser montado por personas adultas. **P:** Tem de ser montado por adultos. **DK:** Skal samles af voksne. **S:** Måste monteras av vuxna. **FIN:** Ainoastaan aikuisen koottavaksi. **N:** Må monteres av voksne. **H:** Csak felnőtt felügyelete mellett használható. **CZ:** Montáž provede dospělá osoba. **PL:** Musi być montowany przez dorosłych. **GR:** Πρέπει να συναρμολογηθεί από ενήλικες. **RUS:** Монтаж должен быть выполнен взрослыми. **TR:** Yetişkinler tarafından kullanılmalıdır. **SI:** Postavitev izključno s strani odraslih oseb. **HRV:** Postavljanje je dozvoljeno isključivo odraslim osobama. **SK:** Montovať smie len dospelá osoba. **BG:** Трябва да се монтира от възрастни лица. **RO:** Trebuie montat de adulți. **UA:** Встановлюється дорослими. **AR:** يتعين تجميعه من قبل أحد البالغين.

