

# **VEVOR<sup>®</sup>**

**TOUGH TOOLS, HALF PRICE**

Technical Support and E-Warranty Certificate [www.vevor.com/support](http://www.vevor.com/support)

## **Electric slicer for fruit and vegetable**

**MODEL:SL-06/SL-08**

We continue to be committed to provide you tools with competitive price.

"Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.



# VEVOR®

TOUGH TOOLS, HALF PRICE

Electric slicer for fruit and  
vegetable

MODEL:SL-06/SL-08



**SL-06**





**SL-08**

## NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us:

**Technical Support and E-Warranty Certificate**  
**[www.vevor.com/support](http://www.vevor.com/support)**

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

|                                                                                  |                                                                                                     |
|----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------|
|   | <b>Warning-</b> To reduce the risk of injury, the user must read the instructions manual carefully. |
|  | Indoor Use Only                                                                                     |

## IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should be followed, including the following.

### **1.READ ALL INSTRUCTIONS.**

### **2.Unplug from the outlet when not in use, before putting on or taking off parts, and before cleaning.**

3.Please check that the specified supply voltage in the product is consistent with the supply voltage(AC only).

4. This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.

5.Children shall not play with the appliance. Cleaning and user maintenance shall not be done by children without supervision.

6.To protect against electrical hazards, do not put the Electric slicer for fruit and vegetables in water or other liquids

7. Avoid contact with moving parts.

8. Do not operate the Electric slicer for fruit and vegetables or any other electrical equipment with a damaged cord or plug or after the unit malfunctions or is dropped or damaged in any manner. Return it to the nearest authorized service facility for examination, repair, or adjustment.

9. Do not use outdoors. **FOR HOUSEHOLD USE ONLY**

10. Do not let the cord hang over the edge of the table or counter or touch hot surfaces.

11. Put this instruction manual in a safe place. Do not discard.
12. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.
13. **Electric Shock Danger!** Non-professional personnel are forbidden to repair the products; otherwise, it may result in electrical shock. When failures happen, they should be repaired by qualified maintenance personnel.
14. **WARNING!** It is strictly prohibited to put the main body of the machine and the power cord into any liquid. The machine must be fully cool before cleaning.
15. Do not place the product directly on the fire or near the source of fire. Otherwise the product will be damaged or even result in danger. Once part of the product is on fire, do not directly use water to extinguish the fire. Use a wet cloth to cover the fire site.
16. When the plug is plugged into the socket, it must be plugged into the end. Otherwise, it will cause the components to overheat and burn due to poor contact.
17. Do not leave the product to work with no one watching. If the machine is overheating, please stop working immediately and unplug the power.

## SAVE THESE INSTRUCTIONS

## CORRECT DISPOSAL



This product is subject to the provision of European Directive 2012/19/EU. The symbol showing a wheeled bin crossed through indicates that the product requires separate refuse collection in the European Union. This applies to the product and all accessories marked with this symbol. Products marked as such may not be discarded with normal domestic waste, but must be taken to a collection point for recycling electrical and electronic devices.

## FCC Information

**CAUTION:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment!

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This product may cause harmful interference.
- 2) This product must accept any interference received, including interference that may cause undesired operation.

**WARNING:** Changes or modifications to this product not expressly approved by the party. Responsible for compliance could void the user's authority to operate the product.

**Note:** This product has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This product generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning the product off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the distance between the product and the receiver.
- Connect the product to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for assistance.

# Summarize

This product has a hand-integrated slicer, high efficiency, light structure, and easy to disassemble and wash. Applicable to various places such as shops, restaurants, stalls, milk tea shops, canteen, households and other fruit and vegetable slice processing. Slice thickness adjustable. The cut pieces are even and easy to see. Green environmental protection, maintain the original flavor, welcomed by users.





Hot pot



Cante



Fruit tea

**Easily handle all  
knife needs in all**



Fast food



Vegetable Shop



Milk tea shop

## 1.Installation operation of the machine

Take out the machine, install the handle on the cutter head with a screwdriver and fix the nut with an inner Hexagon wrench. Then the machine base is sheathed with suction cup (stainless steel, Marble and other smooth table can be directly with 6 small suction cups; wood and other non-smooth table can be randomly equipped with screws fixed). The slicing operation can be carried out after installation.

**Humanized  
handle,Shaking  
slices is easy and  
easy to cut out  
even slices of  
fruits and  
vegetables**



**Solid sucker  
Widening design,  
more suction,  
more stable slice**





## Easy Slice in three steps

Simple operation, everyone can use



Put in the ingredients  
and pull the push rod



Adjust slice thickness  
turn nut, adjust slice thickness



**Cut cabbage**



**Chop ginger**



**Cut potatoes**



**Chop chorizo**



**Cut the apple**



**Cut Lotus root**



**Cut lemon**



**Cut the cucumber**



**Cut radishes**

## **2.Thickness adjustment**

Put the food into the groove and try to cut it to see the thickness. If it is not suitable, you can adjust the thickness. (1): Pull the outer ring of the adjusting knob out, (2) gently turn the knob to turn left and right, In the counter-clockwise direction to adjust the thickness; to the clockwise direction to adjust the thickness, the knob card back to the card slot; the thickness will not run. Pay attention to the feeling in your hand. If there is any resistance to rotation, it means that it has been rotated to the end. Or you'll wear out the adjusting thread.)

## **Spring assisted propulsion**

The spring drives the material into the knife, saving time and effort to prevent cutting hands

Thickness adjustable  
to meet multiple  
requirements



Elastic pull ring  
spring automatic  
propulsion



Large caliber  
trough, easy to  
deal with a variety



### 3.Step to replace spring

First, you need to remove the cutter head and then remove the tie rod tail pentagram; the push plate can be removed to replace the spring. Replace the spring, install the return groove on the push rod, fix it in place with the pentagram, and install the cutter head. Lock the cutter head with the safety buckle for normal use.



Screw out the pull



Removed push plate,  
pull rod, spring



Replace the spring and  
install it back the same

## 4.Cleaning

After slicing, the machine should be cleaned, the whole machine should be cleaned, or the cutter head should be cleaned. After cleaning, it is recommended to dry the water stains to keep the fuselage clean and prevent rusting. (**Note:** Do not use dishwasher to clean cutter head and fuselage)

## 5.Procedure of removing cutter head

- ( 1 ) Pull the buckle out and take off the safety buckle.
- ( 2 ) The cutter head can be washed, or the blade can be replaced by drawing out the cutter head.



**Just remove the safety  
buckle**



**Remove cutter  
head**



**Easy rinse**

**Note:** If there is any technical change, please refer to the nameplate on the product without further notice.

**Manufacturer:** Shanghaimuxinmuyeyouxiangongsi

**Address:** Shuangchenglu 803nong11hao1602A-1609shi, baoshanqu, shanghai 200000 CN.

**Imported to AUS:** SIHAO PTY LTD. 1 ROKEVA STREETEASTWOOD NSW 2122 Australia

**Imported to USA:** Sanven Technology Ltd. Suite 250, 9166 Anaheim Place, Rancho Cucamonga, CA 91730

|           |            |
|-----------|------------|
| <b>UK</b> | <b>REP</b> |
|-----------|------------|

YH CONSULTING LIMITED. C/O YH Consulting  
Limited Office 147, Centurion House, London  
Road, Staines-upon-Thames, Surrey, TW18 4AX

|           |            |
|-----------|------------|
| <b>EC</b> | <b>REP</b> |
|-----------|------------|

E-CrossStu GmbH  
Mainzer Landstr.69,  
60329 Frankfurt am Main.



**VEVOR<sup>®</sup>**

**TOUGH TOOLS, HALF PRICE**

**Technical Support and E-Warranty Certificate**

**[www.vevor.com/support](http://www.vevor.com/support)**