



Transmitter Bluetooth AUX OUT 2xRCA



BLOW

PL

Zawartość opakowania:


1. Odbiornik - 1 szt.

2. Kabel audio 3,5mm - 1 szt.

3. Kabel RCA - 1 szt.
4. Kabel do ładowania - 1 szt.

5. Instrukcja obsługi - 1 szt.

Opis urządzenia



Przewodnik użytkownika:

1. Odtwarzanie/Pauza: Krótkie naciśnięcie przycisku odtwarza lub pauzuje muzykę.

2. Zmiana trybu: Długie naciśnięcie przełącza między trybem karty TF a trybem bezprzewodowym.

Urządzenie zostało zaprojektowane do użytku z radiami samochodowymi, głośnikami, słuchawkami, starszymi systemami audio oraz większością urządzeń mobilnych wyposażonych w porty 3,5 mm lub RCA. Umożliwia przekształcenie zwykłych głośników w bezprzewodowe, transmitując dźwięk z urządzeń mobilnych do samochodów lub domowych systemów audio.

BLOW

PL

Krok 1. Włączanie urządzenia:

Podłącz kabel 3,5 mm lub kabel RCA do głośnika, a następnie podłącz zasilanie. Urządzenie włączy się automatycznie.

Krok 2. Parowanie ze smartfonem:

1. Włącz funkcję bezprzewodową w ustawieniach telefonu i wyszukaj urządzenie "C52". Po udanym sparowaniu możesz odtwarzać muzykę ze smartfona.
(Możesz również włączyć funkcję NFC w telefonie i zbliżyć go do obszaru NFC urządzenia. Dzięki temu połączenie będzie szybkie i łatwe. Telefon musi obsługiwać funkcję NFC).

2. Po udanym sparowaniu możesz odtwarzać muzykę bezprzewodowo, a urządzenie będzie umożliwiać odtwarzanie i pauzowanie muzyki.

3. Po pierwszym sparowaniu telefon będzie automatycznie łączyć się z urządzeniem przy każdym włączeniu.

Tryb karty TF:

Włóż kartę TF, aby odtwarzać muzykę bezpośrednio z karty. Długie naciśnięcie przycisku wielofunkcyjnego przełącza urządzenie w tryb bezprzewodowy.

Uwaga: Jeśli parowanie się nie powiedzie, wyłącz funkcję bezprzewodową w telefonie, wyłącz i włącz ponownie adapter, a następnie powtórz kroki.



BLOW

EN

Package contents:


1. Wireless receiver - 1 pcs

2. 3.5 mm audio cable - 1 pcs

3. RCA cable - 1 pcs
4. Charging cable - 1 pcs

5. User manual - 1 pcs

Product description



User guide:

1. Play/Pause: Short press the button to play or pause the music.

2. Mode switch: Long press to switch between TF card mode and wireless mode.

The device is designed for use with car radios, speakers, headphones, older audio systems, and most mobile devices equipped with 3.5 mm or RCA ports. It transforms ordinary speakers into wireless ones, transmitting sound from mobile devices to cars or home audio systems.

BLOW

EN

Step 1. Powering on the device:

Connect the 3.5 mm or RCA cable to the speaker, and then plug in the power. The device will turn on automatically.

Step 2. Pairing with a smartphone:

1. Enable the wireless function in your phone's settings and search for the "C52" device. Once paired successfully, you can play music from your smartphone, and the sound will be transmitted to the speakers.
(You can also enable the NFC function on your phone and bring it close to the NFC area of the device for fast and easy pairing. Your phone must support NFC.)

2. After successful pairing, you can play music wirelessly, and the device will allow you to play/pause the music.

3. After the first pairing, your phone will automatically reconnect to the device every time you turn it on.

TF card mode:

Insert a TF card to play music directly from the card. Long-press the multifunction button to switch to wireless mode.

Note: If pairing fails, turn off the wireless function on your phone, turn off and restart the adapter, then repeat the steps.



说明书尺寸：60x75mm 正反双面折页