


INSTALLATION MANUAL


RIGHT side installation







SEV-PN-J02BF series

1


TOOL PICTURE



ACCESSORY LIST


A		x1	B		x1	C		x1	D		x1	E		x1			
F		x1	G		x1	H		x1	I		x1	J		x2			
K		x1	L		x4	M		4x30	x4	N		4x30	x1	O		4x16	x2
		x1															

2




SIZE	X	A	B	C
700x1400	700-715	1367	662	647
800x1400	800-815	1367	762	747


3




4




5



6




7



INSTALLATION MANUAL


LEFT side installation




SEV-PN-J02BF series

1


TOOL PICTURE



ACCESSORY LIST


A		x1	B		x1	C		x1	D		x1	E		x1			
F		x1	G		x1	H		x1	I		x1	J		x2			
K		x1	L		x4	M		4x30	x4	N		4x30	x1	O		4x16	x2
		x1															

2




SIZE	X	A	B	C
700x1400	700-715	1367	662	647
800x1400	800-815	1367	762	747


3




4



5



6



7

