





USER GUIDE




1




2




3



4




5




6


Settings → Mobile Data




Settings → Wi-Fi




7




8




9




10




11




12




13




14



15



16



17

 **24/7**

support@deeper.eu
www.deepersonar.com

