

E-HAT



PL



E-HAT



ENG



KONFIGURACJA

1. Podłącz czapkę do odpowiedniego zasilania (power bank / 3,7V).
2. Naciśnij i przytrzymaj przez ok 2-3s przełącznik kontroli temperatury znajdujący się na przodzie czapki, aby aktywować funkcję ogrzewania. Dioda powinna się zaświecić.
3. Ogrzewanie posiada 3 stopnie intensywności. Pojedyncze naciśnięcie przycisku spowoduje zmianę aktualnego trybu:
 - a. czerwona dioda - wysoka temperatura (ok 55°C)
 - b. biała dioda - średnia temperatura (ok 45°C)
 - c. niebieska dioda - niska temperatura (ok 35°C)
4. Naciśnij i przytrzymaj przez ok 2-3s przełącznik kontroli temperatury, aby wyłączyć funkcję ogrzewania. Dioda powinna zgasnąć.
5. Produkt posiada dwie strefy grzewcze.

CZYSZCZENIE, KONSERWACJA I DODATKOWE INFORMACJE

1. Odłącz i wyjmij zasilanie przed przystąpieniem do czyszczenia.
2. Używaj delikatnych detergentów. Zalecane jest delikatne pranie ręczne. Pranie maszynowe jest dozwolone jedynie w niskiej temperaturze, w woreczku ochronnym i na niskich obrotach.
3. Zaleca się naturalne suszenie na powietrzu.
4. Zawsze upewnij się, że ubranie jest całkowicie suche przed jego ponownym użyciem. Nigdy nie podłączaj do zasilania mokrego ubrania.
5. Jeżeli dojdzie do zamoczenia ubrania, niezwłocznie wyłącz funkcję grzania i odłącz zasilanie.
6. Czas ogrzewania zależy od pojemności powerbanku oraz od ustawionego programu pracy. Przykładowo przy pojemności akumulatora 3400mAh czas pracy wynosi ok 4h dla wysokiego, ok 6h dla średniego oraz ok 8h dla niskiego trybu grzania.



Instrukcję w innych wersjach językowych znajdziesz na naszej stronie internetowej.

CONFIGURATION

1. Connect the hat to the appropriate power supply (power bank / 3,7V).
2. It works for about 2-3s to control the temperature control on the front of the hat to activate the heating function. The diode may light up.
3. The heating has 3 local levels. Single press the button to turn off the current mode:
 - a. red diode - high temperature (approx. 55°C)
 - b. white diode - medium temperature (approx. 45°C)
 - c. blue diode - low temperature (approx. 35°C)
4. Press for about 2-3s to control the temperature to turn on the heating function. The diode should turn off.
5. The product has two heating zones.

CLEANING, MAINTENANCE AND ADDITIONAL INFORMATION

1. Disconnect and unplug the power before cleaning.
2. Use mild detergents. Gentle hand washing is recommended. Machine washing is only allowed at low temperature, in a protective bag and at low speed.
3. Natural air drying is recommended.
4. Always make sure that the garment is completely dry before reusing it. Never plug in wet clothing.
5. If the garment gets wet, immediately turn off the heating function and unplug the power.
6. The heating time depends on the capacity of the power bank and the set work program. For example, with a battery capacity of 3400mAh, the working time is about 4 hours for high, about 5 hours for medium and about 8 hours for low heating mode.



You can find instructions in other languages on our website.