


INSTALLATION MANUAL


RIGHT side installation



SEV-PN-209 Series

1


TOOL PICTURE



ACCESSORY LIST


A	B	C	D	E
				
x1	x1	x1	x2	x1
F	G	H	I	J
				
x1	x1	x1	x1	x2
K	L	M	N	O
				
x2	x1	4x30	4x30	4x16
P	Q	R	3MM	Ø3.2mm
x1	x4	x1	x1	x1

2




SIZE	X	A	B	C	D
800x1400	800-815	1367	364	384	383
1000x1400	1000-1015	1367	464	484	483


3




4




5



6




7




8


Black line outside



9




10



INSTALLATION MANUAL


LEFT side installation



SEV-PN-209 Series

1


TOOL PICTURE



ACCESSORY LIST


A	B	C	D	E
 x1	 x1	 x1	 x1	 x1
F	G	H	I	J
 x1	 x1	 x1	 x1	 x2
K	L	M	N	O
 x2	 x1	 4x30 x4	 4x30 x1	 4x16 x2
P	Q	R		
 x1	 x4	 x1	 3MM x1	 Ø3.2mm x1

2




SIZE	X	A	B	C	D
800x1400	800-815	1367	364	384	383
1000x1400	1000-1015	1367	464	484	483


3




4




5



6




7




8

Black line outside



9



10

