




Instrukcja montażu

Lista części

Kod	Obrazek	Opis	Qty
A		Podstawa	1
B		Tuba	1
C		Śruba regulacyjna	1
D		Śruba	1
E		Adapter	1
F		Adapter	1



Informacje ogólne i wskazówki dotyczące bezpieczeństwa

- Przed użyciem upewnij się, że wszystkie śruby są całkowicie dokręcone!
- Zawsze umieszczaj podstawę na stabilnej, płaskiej powierzchni.
- Upewnij się, że śruby regulacyjne są całkowicie dokręcone wokół słupa parasola przed pozostawieniem podstawy parasola wolnostojącej.
- Rura parasola pasuje do kija parasola o szerokości od 38mm do 48mm.
- Tylko do użytku domowego. Nie do użytku komercyjnego.


Ostrzeżenia producenta



Producent nie odpowiada za:

- Przedmioty używane do celów komercyjnych, kontraktowych lub innych celów niemieszkalnych.
- Modele wystawowe lub przedmioty zakupione "jak jest".
- Przedmioty uszkodzone w wyniku działań natury, wandalizmu, niewłaściwego użytkowania lub niewłaściwego montażu.
- Odbarwienie lub blaknięcie wykończenia lub tkanin jako rezultat ekspozycji na działanie czynników chemicznych lub rozlanych płynów.
- Korozja lub rdzewienie sprzętu oraz uszkodzenia ram lub spawów spowodowane przez niewłaściwy montaż, niewłaściwe użytkowanie lub przyczyny naturalne.

Assembly instructions

Parts list

Code	Image	Description	Qty
A		Base	1
B		Tube	1
C		Adjusting screw	1
D		Bolt	1
E		Coupler	1
F		Coupler	1



General information and safety instructions

- Be sure all bolts are tightened completely before use!
- Place base on sturdy, flat surface at all times.
- Be sure adjusting screws are tightened completely around the umbrella pole before leaving the umbrella base free standing.
- Umbrella tube fits umbrella pole from 38mm to 48mm wide.
- For residential use only. Not for commercial use.

Manufacturer's Warning

- The manufacturer is not responsible for:
Items used for commercial, contract, or other non-residential purposes.
- Display models or items purchased „as is”
- Items damaged due to acts of nature, vandalism, misuse or improper assembly.
- Discoloration or fading of the finish or fabrics as a result of exposure to the elements, chemicals or spills.
- Corrosion or rusting of hardware and damages to frames or welds caused by improper assembly, misuse or natural causes.