



DRAGONHAWK



DRAGONHAWK

THE BEGINNING IS THE PEAK

USER INSTRUCTION



- A Function button**
- Long press the button: the startup mode, or shutdown mode
 - Quickly press button: pause / start
 - "+" to increase voltage button
 - "-" to decrease voltage button
- B Screen**
- Timing function: the timing starts after the machine works, the timing stops after the machine stops working, and the timing function is cleared after shutdown
 - Working state display
 - Battery power display
 - Voltage value display
- C Seven Strokes 2.4-4.2mm**
- Rotate to adjust stroke
- D Grip**
- Rotate the grip to adjust the length of needle
- E Cartridge linkage**
- Put cartridge into E, tighten it
- F Replaceable RCA Connecting Part**
- Twist the battery to pull out it, then put in the RCA connecting part
- G Charging interface**
- H Type-c Charging Port**
- I RCA Clip Cord**

PARAMETER

Motor Type	Coreless motor	Input Voltage	4V-12V
Stroke	4.2mm	Battery Capacity	1500mAh

PRECAUTIONS


Recommended to use 5V1A charger to avoid affecting the battery life
Not recommended to charge while working for a long time, otherwise the service life may be affected.

Please keep the machine in a cool and dry place away from children
Batteries, electronic equipment boxes and electrical equipment shall not be disposed of together with domestic garbage

This product is designed to work at a maximum temperature of 40 degrees Celsius and an altitude of 2000 meters

If you have more questions, please contact our official account.
Dragonhawk tattoo supply official

INSTRUKCJA OBSŁUGI



- A Przycisk funkcyjny**
- Długie naciśnięcie przycisku: tryb uruchamiania lub tryb wyłączenia
 - Szybkie naciśnięcie przycisku: pauza / start
 - Przycisk "+" do zwiększania napięcia
 - "-" do zmniejszania napięcia przycisk
- B Ekran**
- Funkcja pomiaru czasu: pomiar czasu rozpoczyna się po uruchomieniu urządzenia
 - Czas zatrzymywania się po zatrzymaniu urządzenia pracy, a funkcja pomiaru czasu jest usuwana po wyłączeniu
 - Wyświetlanie stanu pracy
 - Wyświetlanie mocy akumulatora
 - Wyświetlanie wartości napięcia
- C Siedem skoków 2,4-4,2 mm**
- Obróć, aby dostosować skok
- D Uchwyt**
- Obróć uchwyt, aby dostosować długość igły
- E Łącznik kasety**
- Włóż wkład do E, dokręć
- F Wymienna część łącząca RCA**
- Przekręć baterię, aby ją wyciągnąć, a następnie włóż złącze RCA część łączącą
- G Interfejs ładowania**
- H Port ładowania typu C**
- I Przewód z klipsem RCA**

PARAMETR

Typ silnika	Silnik bezzrzedniowy	Napięcie wejściowe	4V-12V
Udar	4.2mm	Pojemność akumulatora	1500mAh

ŚRODKI OSTROŻNOŚCI

Zaleca się używanie ładowarki 5V1A, aby uniknąć wpływu na żywotność baterii.
Nie zaleca się ładowania podczas pracy przez długi czas, w przeciwnym razie może mieć wpływ na żywotność.

Urządzenie należy przechowywać w chłodnym i suchym miejscu, z dala od dzieci.
Baterie, pudełka po sprzęcie elektronicznym i urządzenia elektryczne nie powinny być wyrzucane razem ze śmieciami domowymi

Ten produkt został zaprojektowany do pracy w maksymalnej temperaturze 40 stopni Celsjusza i wysokości 2000 metrów

Jeśli masz więcej pytań, skontaktuj się z naszym oficjalnym kontem.
Dragonhawk tattoo supply official