thinkplus Live Pods XT92



使用说明书 使用前请阅读使用说明书

产品规格 有效距离: ≥10m 喇叭直径: ◊10mm 喇叭功率: 10mW*2

阻抗: 32Ω 麦克风灵敏度: -40dB ± 3dB 信噪比: ≥95dB 失直度, ≤3% 類率响应, 20Hz-20KHz

播放时长,约4小时 耳机电池容量。30mAh 充电仓电池容量: 300mAh

(所有技术信息以实际性能为准)

物品清单 蓝牙耳机 x2

充电线 x 1 充 电盒 x 1 说 明书 x 1 耳 帽 x 6



产品注意事项

(1)除说明书有特殊标示的操作方式以外,请勿尝试拆卸或更换产品 内的红荷要件

(2)本产品含内置可充电电池,禁止撞击、挤压、刺破、短路电池,若出 邓温度过高、变形、鼓胀、漏液等异常现象,请停止使用,请勿置电池于 明火、阳光爆晒、加热器、火炉等高温以及高压环境中,电池浸水后禁 止使用。耳机使用后,勿将耳机放在潮湿、充满灰尘、油烟、蒸气、阳 光直射等高温高压等环境中,以免造成耳机及电池损坏。电池可充放电 次数有限,最终会老化,电池使用异常时可更换新电池,但切勿自行更换电 池 如果由池更换不当会有爆炸危险 只能通过售后服务商更换同等类型 或者等效举型的由池使用。

(3)产品使用报废后,勿将产品扔置火中,废旧处理应严格按照垃圾分类 进行处理。请合理正确的使用此产品,以免造成一定的伤害和环境破坏。 (4) 在耳机使用过程中,由于远距离、中间有障碍物或者有其他无线 电信号、蓝牙信号、WIFI信号等一系列的干扰的情况下,耳机在使用时 听音乐、看视频、玩游戏等情况下,会出现偶尔的卡顿、语音不同步或

者断连的情况,如出现此情况请重新连接耳机或者远离干扰物。

(5) 充电时充电器请使用输出电压为直流DC 5V/1A的充电设备, 必 须选择正规生产厂家获得CCC安全认证过的充电设备,请勿使用快充充 电器,以免造成电池负载太大,而产生电池损坏。连续充电时间请勿超 过规定的充电时间,充电时请勿使用,以免造成损坏。

安全与有效使用指南

注意, 请在使用蓝牙耳机前首先阅读此信息。

用户如果未经许可而对此蓝牙耳机进行改动或改装,将丧失继续享 有该设备所含服务的权利。

1 电磁干扰。 电子设备: 为避免电磁干扰或配置不兼容的影响,遗在标有明确指示的场

所中按照规定关闭您的蓝牙设备。

航; 登机后,请根据乘务人员的提示关闭您的蓝牙耳机。飞行中严 禁使用蓝牙耳机,以免对飞机通信系统产生干扰。

置: 建议您在不使用蓝牙耳机时,将其放置在不受挤压的地方, 护 压有可能会导致产品的损坏或人身的伤害。

章: 不要让儿童玩弄蓝牙耳机,其中—些小部件可拆卸,有可能被吞 咽而造成危险。

方式—,将左右耳机从杂由仓取出、耳机开机。

方式一, 目机关机构状态下(在杂由合外), 长钟左右耳机多功能钟 摸键约3秒,耳机开机。

方式一: 将开机状态下的左右耳机直接放入充电仓, 耳机关机。

关机;超出信号有效连接距离,未与相应蓝牙设备连接,5分钟后,耳 机自动关机。 3.TWS配对

a.左右耳机无配对记录的情况下,左右耳机开机后,自动进行配对。 b.左右耳机有配对记录的情况下, 开机自动回连。

(左)耳播放(并继续保持切换前的音乐状态)。

耳的正常工作。 c.TWS连接后任意单耳使用过程中,取出另一耳机可自动TWS连接,

左右耳继续当前工作状态。 d 单独开启左耳或右耳, 都可同连手机。

5.与英芽设备进行职划连接 打开准备配对的蓝牙设备的蓝牙设置洗项、进入洗项、找到耳机的蓝牙 配对名"联想 thinkplus XT92",点击配对名进行配对。

6.播放音乐 上一曲,连续短触左耳耳机多功能触模键三次

7. 电话免提(双耳机配对操作)

8.电话免提(单耳机操作)

9.激活语音助手

音量减. 长按右耳魨模位1.5秒可减小-级音量

来电时,接听,短触任意耳机多功能触模键-次

来电时, 拒接, 长触任意耳机多功能触模键—秒钟

结束诵话挂断,在接诵电话状态下,短触任意耳机多功能触模键--次

激活语音助手: 耳机与手机连接成功后, 二击触摸位, 可激活语音助手。

蓝牙斯连, 左(右) 耳机指示灯呈绿灯闪烁。(右) 左耳指示灯熄灭。

充电仓给耳机充电, 充电仓在给耳机充电过程中, 耳机指示灯呈绿灯常

东电仓东电, 东电器给东电仓东电过程中, 东电仓绿色灯闪烁, 当东满

暂停/播放、短触任意耳机多功能鈍模键--次

来电时,接听:短触耳机多功能触摸键-次

来电时, 拒接: 长触耳机多功能触摸键一秒

结束诵话挂断、短触耳机多功能触模键--次

对互组队成功, 左(右)互机指示灯呈绿灯闪烁。

对耳组队断开, (左)右耳机指示灯呈绿灯闪烁。

蓝牙配对成功, (左)右耳机指示灯熄灭。

高: 当充满电后, 耳机指示灯熄灭。

(右) 左耳机指示灯熄灭。

下一曲,连续短触右耳耳机多功能触摸键三次 音量加、长按左耳鈍模位1.5秒可增大-级音量

方式二: 处于开机状态下的左右耳机多功能键触摸键约5秒, 耳机关机, 注: 当耳机开机后,5分钟未与相应蓝牙设备进行配对连接,便会自动

> 10 投示打思示 耳机开机, (左)右耳机指示灯绿灯常亮。 耳机关机, (左)右耳机指示灯呈绿灯快闪3次后熄灭。

4.左右耳自动切换 a.耳机使用过程中,把左(右)耳放进充电盒充电,会自动切换到右

b.耳机使用过程中, 把左(右)放进充电盒充电, 不会影响右(左)

电后级色灯常亮。

产品中有害物质名称及含量

产品中有害物质的名称及含量

部件名称	有害物质					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多澳二苯 (PBDE)
印刷电路组件	0	0	0	0	0	0
外壳等小结构件	0	0	0	0	0	0
外壳等小结构件	0	0	0	0	0	

本表格依据SJ/T 11364的规定编制。

表示该有害物质在该部件所有均质材料中的含量均在 GR/T 26572 柳完的原量要求以下。

· 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。 表单标记"X"的部件,皆因全球技术发展水平限制而无法实现有害

印刷电路板组件*:包括印刷电路板及其零部件,电子元器件等, 根据产品型号不同, 您所购买的产品可能不会含有以上所有部件



在中华人民共和国境内销售的电子电气产品必须标识此 标志, 标志内的数字代表在正常的使用状态下的产品的 环保使用期限。

台書書明

本使用手册没有任何形式的担保、立场表达或其他暗示,本使用手册所 提到的产品、规格及信息仅供参考,内容亦会随时更新于网页,恕不另

保修声明.

就本文件附随的产品做如下保证:如产品在您购买日起十二(12)个月 ("保修期")内,在下常使用情况下因质量瑕疵发生损坏,能修理的 . 免费修理:经厂家确认无法修理的、免费更换:修理或更换后的产品 , 在剩余保修期(最短不少于30天)内继续享有保修。购买日以销售发 型日期为准: 如无法确定购买日、则保修期白产品生产日期起按十二 (13) 个月计算。

如申请保修,请先致电产品服务热线,并按我们指示的方式执行。 申请保修时,您需要提供准确、完整和清晰填写的有效销售发票。

以上保证不适用于下列情况: 1.超过三包有效期的;

2.涂改保修卡、产品编码与产品本体不符; 3.因误用、滥用或不适当的运输、使用、维护或保管而导致的故

4.因不可抗力(如地震、战争、火灾等)或意外导致的故障或损

5.拉链、塔扣因受力过大而损坏; 因承载过重造成的脱线或撕裂;

7.任何因尖锐物体造成的损坏; 8.有烧损或水浸迹象的产品; 9.因擅自拆改导致的损坏;

10.产品正常使用过程中发生的老化、脱色、磨损、破裂和其他损耗。

11 加产品原有标识标签被更改或损毁。本保证将失效。 产品及随附物料的齐备和外观完好不属于保证范围,您应在接收产品时 当场检验并对任何不符提出显议。

以上保证是我们就产品做出的全部保证,且仅在中国大陆地区境内适用 。本文件的任何内容均不影响根据法律规定不能排除或限制的消费者权

服务监督热线: 400-812-0102

售后邮箱: frank@szeysan.cn

"Lenovo", "thinkplus" 是联想集团所属企业的商标,提及 的其他公司、产品和服务名称可能是其他公司的商标。 版权所有@2022联想集团所属企业和其许可方保留所有权利。 此产品仅限中国大陆地区销售。

thinkplus Live Pods XT92



USER MANUAL PLEASE READ ALL INSTRUCTIONS CAREFULL AND RETAIN FOR FUTURE USE

Product energifications Effective distance: ≥ 10m Impedance: 32 \O Microphone sensitivity: - 40dB ± 3dB SNR: ≥ 95dB Distortion: ≤ 3% Duration: about 4 hours Earphone battery capacity: 30mAh Battery capacity of charging chamber: 300mAh

(All technical data is subject to actual performance)

Bluetooth headset x 2 Charging box x 1 Ear cap x 6

Do not try to disassemble or replace the product except for the operation methods that are specially marked in the manual Any part

This product contains a built-in rechargeable battery. It is forbidd to hit squeeze nuncture or short-circuit the battery If the current temperature is too high, deformation, swelling, liquid leakage and other abnormal phenomena, please stop using it and do not place the battery in the In high-temperature and high-pressure environments such as open flames, sun exposure, heaters, stoves, etc., the battery should not be immersed in water. Stop use.

After using the headset, do not place the headset in damp, dust, oily smoke, steam. In high temperature and high pressure environments such as direct light, so as not to cause damage to the headset and battery. The battery can be charged and discharged for a limited number of times, and it will eventually age, When the battery s used abnormally, you can replace the battery with a new one. However, do not replace the hattery by yourself. If the hattery is ncorrectly replaced, there is a danger of explosion, Battery usage (3) After the product is scrapped, do not throw the product into the fire, and the waste treatment should be strictly in accordance with the garbage classification To process. Please use this product reasonably and correctly, so as not to cause certain harm and environmental

(4) During the use of the headset, due to long distances, obstacles in the middle, or other wireless In the case of a series of interference such as electrical signal, Bluetooth signal, WIFI signal, etc., when the earphone is in use, listening to music, watching video, playing games etc., there will be occasional freezes, unsynchronized voice or disconnection, such as In this case, please reconnect the headset or stay away from the interference

(5) When charging the charger, please use a charging device with an output voltage of DC 5V/1A, You must choose charging equipment hat has been certified by a regular manufacturer with CCC safety pertification, and do not use fast charging Electrical appliances, so as not to cause too much battery load, and cause battery damage. he continuous charging time should not exceed the specified. charging time, and do not use it during charging to avoid damage.

Guidelines for safe and effective use

Note: Please read this information before using the Bluetooth headset f the user changes or modifies this Bluetooth headset without permission, he will lose the continued enjoyment, Have the right to the services included in the device.

DElectromagnetic interference: lectronic equipment: To avoid the influence of electromagnetic nterference or configuration incompatibility, pleaseTurn off your Bluetooth device in accordance with the regulations. Civil Aviation: After hoarding, please turn off your Bluetooth heads: according to the instructions of the flight attendant, It is strictly forbidden to use Bluetooth headsets in flight to avoid interference with the aircraft communication system. Safety matters

Placement: It is recommended that you place the Bluetooth headse in a place where it will not be equested when not using it Pressure may cause product damage or personal injury. Children: Don't let children play with Bluetooth headsets, some of th small parts are detachable and may be swallowed. Swallow and cause

Product operation instructions

Method 1: remove the left and right earphones from the charging bi and turn on the earphones.

Mode 2: when the earphone is off (outside the charging bin), touch the left and right earnhone multi-function touch button for about 3 seconds, and the earphone is on. 2. Power off

Method 1: put the left and right earphones in the charging bin directly and turn off the earnhones

Mode 2: the left and right earphone multi-function keys in the powe on state touch the key for about 5 seconds, and the earphone is turned off Note: when the headset is turned on, it will automatically turn off if it

is not paired with the corresponding Bluetooth device for 5 minutes; Reyond the effective connection distance of the signal, it is not connected with the corresponding Bluetooth device, After 5 minutes, the headset will automatically turn off. . TWS pairing

a. When there is no pairing record between the left and right earphones, the left and right earphones will be paired automatically after they are turned on. b. When the left and right earphones have matching records, they will be automatically connected back when they are turned on 4. Automatic switch between left and right ears a. In the process of using the headset, put the left (right) ear into the

charging box to charge, and it will automatically switch to the right (left) ear to play (and continue to maintain the music state before h. In the process of using the earnhone, but the left (right) into the charging box for charging, which will not affect the normal operation

of the right (left) ear c. After TWS connection, when any one ear is in use, take out anothe headset to automatically connect TWS, and the left and right ears

1. Turn on the left or right ear separately to connect the mobile phone

. Pairing with Bluetooth devices Open the Bluetooth setting option of the Bluetooth device to be paired enter the option, find the Bluetooth pairing name of the headset "

Play music Last song: touch the left ear headset multi-function touch key three times in a row

enovo thinkplus XT92", and click the pairing name to pair.

Next song: touch the right ear earphone multi-function touch key three times in a row

increase the volume by one level Volume reduction: long press the right ear touch bit for 1,5 seconds o reduce the volume by one level

Pause / play: short touch any headset multifunction touch key once , Hands free telephone (paired operation of two earphones) When calling, answer: short touch any headset multi-function touch

When calling, refuse to answer: touch any headset multi-function touch key for one second End the call and hang up: when the call is on, short touch any headset

nultifunction touch key once 8. Hands free (single headset operation When calling, answer; short touch the headset multifunction touch When calling, refuse to answer: long touch the headset multi-function

End call hang up: short touch the headset multi-function touch key 9. Activate voice assistant

Activate voice assistant: after the headset is successfully connected with the mobile phone, double click the touch bit to activate the voice.

10. Indicator light display Earphone power on: (left) the right earphone indicator light is always

Earphone power off: (left) the right earphone indicator light is green, flash 3 times and then go out. Successful pairing: the left (right) earphone indicator is flashing

green, and the left (right) earphone indicator is off. Turn off the opposite ear: (left) the indicator light of the right earphone flashing green. Bluetooth pairing successful: (left) right headset indicator is off.

Bluetooth disconnection: the left (right) headset indicator is flashing green, and the left (right) ear indicator is off, Charging the earphone in charging chamber: during charging the earphone in charging chamber, the earphone indicator light is always green; When fully charged, the headphone light goes out. Charging of charging chamber: during the charging process, the green light of charging chamber flashes, and the green light is always on when it is fully charged.

