



SEVANTE

INSTALLATION MANUAL







SEV-PN-107 series



TOOL PICTURE



ACCESSORY LIST


A  x1	B  x1	C  x1	D  x1
E  x4	F  x2	G  4*16 x2	H  4*30 x4
I  x3	J  x2	K  x4	L  x1
 4MM x1	 Ø3.2mm x1		

1





2

D  x1	H  4*30 x4	K  x4
---	---	--




SIZE	X	A	B	C	D	E
1200x1400	1200-1215	1367	330	390	417	416


3



4



5



6

