


deeper



pro

pro+


pro+2



1



2




3



Auto
ON



Auto
OFF




4




Settings → Mobile Data

1




2




Settings → Wi-Fi

✓ OK

1




2



5


1




2




1







2




6




7




8




9




10





11





12




13




14



15





16



MAPS.FISHDEEPER.COM

17



support@deeper.eu
www.deepersonar.com

18



deepersonar.com/support