





SPEX114

CHILDREN DESK

FOR KIDS • XD SERIES




01 Study Desk Accessories List




02 Desk Assembly Instructions



01. First, use 2 A-type screws to attach one of the table legs to the frame, but do not tighten the screws yet. Then, insert the drive rod through the pre-installed table leg. Next, insert the other leg onto the drive rod (if it doesn't go through easily, use your hand to turn the rod slightly while inserting it into the leg hole, allowing the drive rod to pass through). Then, use 2 A-type screws to secure the leg to the frame, but do not tighten them yet. Finally, use 4 F-type M8*45 screws to attach the two feet to the table legs as shown in the figure below, and tighten the screws.




02. Use four B screws to assemble the left and right table legs, and tighten the screws. Then, tighten the four A screws on the left and right table legs.




02 Bookshelf Installation Instructions




04. First, use 4 A-size screws to attach the drawer assembly to the frame, as shown in the figure below, and tighten the screws; then use 1 A-size screw to attach the backpack hook to the frame, as shown in the figure below, and tighten the screw.




05. Install the eight (C) type 3-in-1 screws into the corresponding holes on the wooden board shown in the figure below, and tighten the screws. Then, use four E type screws to attach the No. 9 bracket to the No. 8 wooden board, and tighten the screws.



1



2




3

4


E

06. As shown in the picture, use four A screws to attach iron plate number 7 to back panel number 6. Make sure to put a plastic spacer between the iron plate and the wood panel. Then use four A screws to attach the reading rack to bookshelf panel number 5!



Plastic gasket


Note that after the screw goes through the metal plate, first put on the plastic washer before attaching it to the wooden board!




5

A

07. As shown in the figure below, use 8 C-type cam locks, 5 D-type dowels, and 2 E-type screws to assemble the corresponding bookshelf panels, and tighten the screws!



08. Use four (D) screws to attach the bookshelf to the desk, as shown in the figure, and tighten the screws. Then attach the (L) hand crank to the desk.



Hand crank

Friendly reminder: After assembling the table, please place it against the wall!



Attention!

This product is intended for children aged 3 and above. It should only be assembled by adults, and children should stay away to prevent contact with or accidental swallowing of the included hardware.

The WEEE symbol (the crossed-out wheeled bin) using indicates that this product is not home waste. Appropriate waste management aids in avoiding consequences which are harmful for people and environment and result from dangerous materials used in the device, as well as improper storage and processing. Segregated household waste collection aids recycle materials and components of which the device was made. In order to get detailed information about recycling this product please contact your retailer or a local authority.



MADE IN P.R.C. FOR
SPACETRONIK SP. Z O.O.
WIŚNIOWA 36
64-000 KOŚCIAN, POLAND
INFO@SPACETRONIK.STORE
SPACETRONIK.STORE

