

INSTRUKCJA MONTAŻU


MONTAŻ ZA POMOCĄ KLEJU- UDŹWIG 5 KG




1. Przed instalacją wyczyść i osusz powierzchnię.



2. Posmaruj klejem brzegi dotykające ściany.



3. Przyklej do ściany i dociskaj przez 3-5 sekund.



4. Przyklej wieszak do ściany taśmą z zestawu od zewnątrz.



5. Pozostaw na 48h.



6. Odklej taśmę. Produkt gotowy do użytku!

UWAGI DODATKOWE

Jeżeli chcesz zdemontować wieszak, użyj suszarki do włosów.

Kieruj na wieszak gorący strumień powietrza przez 5 minut - to znacznie ułatwi usunięcie wieszaka i resztek kleju ze ściany.


OSTRZEŻENIE

Opakowanie oraz torby foliowe nie są zabawką, należy trzymać je poza zasięgiem dzieci, w przeciwnym przypadku istnieje ryzyko uduszenia lub poważnego uszczerbku na zdrowiu.

KONSERWACJA I CZYSZCZENIE

Zalecamy używać środków przeznaczonych do czyszczenia tworzyw sztucznych, nie zawierających środków chemicznych. Stosowanie się do powyższych zaleceń pozwoli na bezpieczną i długą eksploatację. Wady wynikające z niewłaściwego użytkowania nie są podstawą do roszczeń z tytułu reklamacji. Meble przeznaczone do użytku domowego. Elementy ruchome należy konserwować środkami do tego przeznaczonymi.


MONTAŻ Z UŻYCIEM WIERTŁA- UDŹWIG 5 KG



1. Zaznacz miejsca wiercenia i wywierć otwory wielkości 6 mm.



2. Wbij kołki rozporowe w otwory.



3. Użyj śrub, przytwierdź półkę do ściany.



4. Po dokręceniu śrub, produkt jest gotowy do użycia!

1. Produkt instalować na gładkiej, twardej powierzchni.
2. Zawsze upewnić się, czy w wybranej ścianie nie ma przewodów lub rur.
3. Zawsze zakładać gogle ochronne na czas wiercenia. Po skończonej pracy wyłączyć urządzenie z prądu.

OSTRZEŻENIE

Opakowanie oraz torby foliowe nie są zabawką, należy trzymać je poza zasięgiem dzieci, w przeciwnym przypadku istnieje ryzyko uduszenia lub poważnego uszczerbku na zdrowiu.

KONSERWACJA I CZYSZCZENIE

Zalecamy używać środków przeznaczonych do czyszczenia tworzyw sztucznych, nie zawierających środków chemicznych. Stosowanie się do powyższych zaleceń pozwoli na bezpieczną i długą eksploatację. Wady wynikające z niewłaściwego użytkowania nie są podstawą do roszczeń z tytułu reklamacji. Meble przeznaczone do użytku domowego. Elementy ruchome należy konserwować środkami do tego przeznaczonymi.

Installation Instructions

INSTALLING WITH GLUE


MAX LOAD 5KG



1. wipe clean the wall till




2. apply the drill-free glue



3 Press for 3-5 seconds

It is complete dry before install

on the mounting surface



4. Use on-time adhesive tape



5. Wait 48 hours



6. Finish, use

IF YOU WANT TO REMOVE THE UNIT ,JUST AIM THE HAIR DRYER AT THE BONDING AREA AND BLAST WITH HEAT FOR 3-5MINUTES
WARNING!

Packaging and plastic bags are not toys, they should be kept out of the reach of children, otherwise there is a risk of suffocation or serious damage to health.

BONDING AREA AND BLAST

MAINTENACE AND CLEANING


We recommend that you use detergents intended for cleaning plastics, which do not contain chemicals. Following the above recommendations will allow for safe and long operation. Defects resulting from improper use do not constitute grounds for claims arising from the complaint. Intended for home use.

Moving parts should be maintained with agents designed for this purpose.

Step by step Instructions

PREFORATED INSTALLATION


MAX LOAD 5KG




1. Drill holes



2. Hammer in the drywall anchors which are Provided with the towel bar



3. Use the provided screws to secure the mounting brackets to the wall



4. when you are done ,you can use

1. Product should be mounted to smooth and hard wall.
2. Always make sure, that there is no electric wiring or plumbing in place of drilling.
3. Put on the goggles during the drilling. Turn off the device after drilling.

WARNING!

Packaging and plastic bags are not toys, they should be kept out of the reach of children, otherwise there is a risk of suffocation or serious damage to health.

MAINTENACE AND CLEANING

We recommend that you use detergents intended for cleaning plastics, which do not contain chemicals. Following the above recommendations will allow for safe and long operation. Defects resulting from improper use do not constitute grounds for claims arising from the complaint. Intended for home use.

Moving parts should be maintained with agents designed for this purpose.