



- 1** Power on the CRY2620
Press and hold the power button for 2 seconds




- 3** Adjust the Frequency Range
Select a suitable frequency range




Effective test bandwidth:
2kHz-48kHz

- 2** Point the CRY2620 at the Measurement Target



- 4** Photo/Video, record a measurement
-Press the button in the toolbar to switch modes, the available modes are "Photo" and "Video".
-Press the right button to start taking photos or videos.
-Press "Playback" to view saved photos and videos.



[Download User Manual](#)



Scan the QR code above
to download the user manual

Web: www.crysound.com

CRY2620 Base Kit



- 1 CRY2620 Industrial Acoustic Imager
- 2 Hand straps
- 3 TF card
- 4 Shoulder strap



- 1 User Manual
- 2 Certificates
- 3 Earphones
- 4 Power adapter
- 5 Plug adapters
- 6 Charging cable
- 7 Card Reader