


Ediag Elite | Register&Activate&Update


Ediag Elite | Register&Activate&Update

Register new account



You can login with your accooount.



Or click Register Now to register a new account.



Enter your email, a verification code will be sent to your email.



verification code

Enter the verification code

The image displays two side-by-side screenshots of a mobile application interface. The left screenshot, titled "Verification Code", shows a numeric keypad with the code "759057" entered. A green message box states "The verification code has been sent to your email." Below the keypad is a "Resend 41S" button. A modal dialog with a red loading icon and the text "Signing up..." is overlaid on the screen. The right screenshot, titled "Username and Login Password", features two input fields: "Please enter a username." and "Please set a login password." with an eye icon for toggling visibility. A "Submit and sign in" button is positioned below the fields. At the bottom, there is a "Maybe later.Skip" link and a detailed list of requirements for the username and password. Both screens show a status bar at the top with the time "11:48" and a battery level of "55%".

11:48 55%

←

Verification Code

Please enter the received verification code here.

7 5 9 0 5 7

The verification code has been sent to your email.

Resend 41S

Can't receive the v

Signing up...

11:48 55%

←

Username and Login Password

Please enter a username.

Please set a login password.


Submit and sign in

Maybe later.Skip


1.The username must start with a letter and be a combination of 6-20 letters, numbers, underscores (_), and hyphens (-). The username must be unique, so please avoid duplicates.
2.The login password must be a combination of 8-20 letters (case-sensitive), numbers, and characters (only !@#\$\$%^&*. ()).

Set new username and password.


The username should be a combination of 6-20 English letters and numbers, the password should be a combination of 8- 20 English letters and numbers.



If your email has been registered, please click Login with verification code.




A verification code will be sent to your email, enter the verification to login.





Activate device

Click to add device



Enter serial number and activation code, click Activate.



Ediag Elite

Bluetooth Vehicle Diagnostic Tool

Quick Start Manual

Scan to activate device



Serial Number:

9T8P20202530

Activation Code:


90546191

If you have any questions, please contact
the 24/7 customer service in the App.

English


Serial number/Activation code

Or you can scan the QR code to activate



Update

Click All systems diagnostic and download all the vehicle software you need.



Click Maintenance functions and download all the function software you need.

