

Ostrzeżenia:

1. Jeździk przeznaczony jest dla dzieci w wieku od 12 do 36 miesięcy. Waga jeźdźcy nie może przekraczać 25 kg, gdyż nie ma wystarczającej siły, aby utrzymać nadwagę.
2. Produkt przeznaczony jest do przewożenia 1 dziecka na raz, aby uniknąć obrażeń.
3. W celu zapewnienia bezpiecznej jazdy zdecydowanie zaleca się opiekę i nadzór rodziców.
4. Aby zapewnić bezpieczeństwo, wymagany jest montaż i instalacja wszystkich części przez osobę dorosłą.
5. Baterie powinny być obsługiwane przez osoby dorosłe.
6. Uważaj podczas jazdy i unikaj zbliżania się do ulic, skrzyżowań, obszarów o dużym natężeniu ruchu, basenów i schodów.
7. Brak regularnej kontroli produktu spowoduje jego przewrócenie lub upadek.
8. Od czasu do czasu sprawdzaj, czy nakrętka i śruba na kierownicy są dokręcone i zabezpieczone.
9. Nieprawidłowe zmontowanie produktu może powodować zagrożenia.
10. Podczas użytkowania należy nosić buty.

Obsługa baterii:

1. Baterię mogą obsługiwać wyłącznie osoby dorosłe.
2. Zawsze wyjmuj wyczerpane baterie.
3. Używaj wyłącznie baterii typu AAA.
4. Zalecane są baterie alkaliczne.
5. Zawsze wyjmuj baterie, jeśli urządzenie nie będzie używane przez dłuższy czas.
6. Wymieniając nowe baterie, zawsze wymieniaj wszystkie baterie.
7. Nie mieszaj starych i nowych baterii.
8. Nie mieszaj baterii alkalicznych, standardowych (węglowo-cynkowych) ani akumulatorów (niklowo-kadowych).
9. Nie wrzucaj baterii do ognia, baterie mogą eksplodować lub wyciekać.
10. Baterii jednorazowych nie należy ładować ponownie.
11. Przed ładowaniem akumulatory należy wyjąć z zabawki.
12. Akumulatory można ładować wyłącznie pod nadzorem osoby dorosłej.
13. Baterie należy wkładać z zachowaniem właściwej polaryzacji.
14. Nie wolno zwierać zacisków zasilających.

Kod produktu: 667



Jeździk

Instrukcja obsługi



Ostrzeżenie

Wymagany montaż przez osobę dorosłą



Lista komponentów

1. Korpus x1 	2. Kierownica x1
3. Oparcie x1 	4. Patyk w kształcie litery J

„Mercedes-Benz” i stanowi własność intelektualną Mercedes-Benz Group AG. Są używane przez firmę Ningo Prince Toys Co. Ltd na podstawie licencji.

Instrukcja montażu

Krok 1




1. Zainstaluj drążek w kształcie litery J w wyznaczonym miejscu jak na rysunku.

Krok 2



2. Poluzuj śrubę i nakrętkę w kierownicy za pomocą śrubokręta (brak w zestawie)

Krok 3




3. przytrzymaj drążek w kształcie litery J od dołu, następnie umieść kierownicę nad drążkiem w kształcie litery J, włóż śrubę i dokręć nakrętkę śrubokrętem (brak w zestawie)

Krok 4



4. Włóż oparcie z tyłu korpusu i upewnij się, że jest całkowicie osadzone.

Wymiana baterii



Jak wymienić baterię:
- Poluzuj śruby za pomocą śrubokręta.
- Włóż 2 baterie AAA do komory baterii
- Następnie dokręć śrubę śrubokrętem

Warning:

- 1-Ride-on car is designed for children up 12-36 months old. Rider's weight must not exceed 25kgs. as there is insufficient strength to support overweight.
- 2-Product is designed to seat 1 child as a time to avoid injuries.
- 3-Parental guidance and supervision are strongly advised to ensure safe riding.
- 4-Adult assembly and installation of all parts are required to ensure safety.
- 5-Batteries to be handled by adults.
- 6-Take care of riding and avoid going near streets,crossroads,all traffic areas,swimming pools,and stairs.
- 7-Without regular check of the product,it will cause overturn or fall.
- 8-Check to see occasionally that the nut and bolt on the steering wheel is tight and secure.
- 9-Dangers may present if the product is not correctly assembled.
- 10-Shoes must be worn in use.

Battery Handling:

- 1-Battery must be handled by adults only.
- 2-Always remove exhausted batteries.
- 3-Use AAA size batteries only.
- 4-Alkaline batteries are recommended.
- 5-Always remove batteries when the unit is not going to be used for an extended period of time.
- 6-When replacing new batteries,always replace all batteries.
- 7-Do not mix old and new batteries.
- 8-Do not mix Alkaline,Standard(Carbon-Zinc),or Rechargeable(Nickel-Cadmium)batteries.
- 9-Do not dispose of batteries in fire,batteries may explode or leak.
- 10-Non-rechargeable batteries are not to be recharged.
- 11-Rechargeable batteries are to be removed from the toy before being charged.
- 12-Rechargeable batteries are only to be charged under adult supervision.
- 13-Batteries are to be inserted with the correct polarity
- 14-The supply terminals are not to be short-circuited

Item No: 667

Activity Ride-On




Instructions Manual

WARNING
ADULT ASSEMBLY
REQUEST.

**COMPONENTS LIST**

1.Body 1pc 	2.Steering wheel 1pc 
3.Backrest 1pc 	4.J-shaped stick 1pc 


„Mercedes-Benz” and  are the intellectual property of Mercedes-Benz Group AG. They are used by Ningbo Prince Toys Co.,Ltd under license.

INSTRUCTIONS**Step 1**

1.Install the J-shaped stick at the assigned location as picture.

Step 2

2.Loosen the bolt and the nut in the steering wheel by a screwdriver (not included).

Step 3

3.Hold the J-shaped stick at the bottom,then place the steering wheel over the J-shaped stick,insert the bolt and tighten the nut with a screwdriver(not included).

Step 4

4.Insert the backrest into the rear of the body,be certain the backrest in completely seated.

BATTERY CHANGE

How to exchange the battery.
-Loosen the screws with a screwdriver.
-Put 2AAA batteries in the battery house.
-Then tight the screw with a screwdriver.