

BLOW**KS207**

Waga kuchenna Kitchen weight scale

Instrukcja obsługi User manual

Specifications and parameters

- Power display:
- Default unit: g
- Power: $\frac{\text{W}}{\text{Watt}}$
- Manual on/off: Press and hold the $\frac{\text{POWER}}{\text{TIMER}}$ key for 2S
- Minimum weighing: 0.3g
- Maximum weighing: 3000g
- Overload value: 3050g
- Scale values: 0.1g, 0.005oz, 0.1ml
- Automatic power off: 180S
- Power supply: 3.7V (rechargeable lithium battery) 400mA/H
- Prompt sound: When touching $\frac{\text{POWER}}{\text{TIMER}}$ key and $\frac{\text{oz/mg}}{\text{ZERO}}$ key in the boot state, the buzzer emits a "beep".
- Peel function: Press $\frac{\text{oz/mg}}{\text{ZERO}}$ to peel weighing mode

Charging and symbol tips

1. Insert USB charging cable into charging, two stroke segments flash alternately, and other strokes are not displayed.

2. After the full charge is completed, the LED screen displays the symbol "FULL" (2.5H full charge once) and the buzzer rings "Beep", the charging is completed.

3. After charging, dial off the charging cable, and the LED screen display is reset to zero.

4. Overload prompt: When the weighing weight exceeds "3050g"

5. Low voltage prompt: Voltage below 3.0 V

6. Weight instability tips

Unit conversion

- Default unit "g" on power-up "g".
- If the user needs to convert the unit, press and hold $\frac{\text{POWER}}{\text{TIMER}}$ for 2S in the standby state, and press and hold $\frac{\text{oz/mg}}{\text{ZERO}}$ for 2S to enter the cycle of unit conversion "g → oz → ml".

Exit automatic mode

- In manual timing mode, press $\frac{\text{POWER}}{\text{TIMER}}$ for positive timing, press $\frac{\text{POWER}}{\text{TIMER}}$ again, pause or continue. The maximum timing value is 99m: 59s.
- In the positive timing state, double-click the $\frac{\text{POWER}}{\text{TIMER}}$ key to exit the positive timing mode, and the timing is cleared.

Automatic mode

- Switch by double-clicking $\frac{\text{oz/mg}}{\text{ZERO}}$ key when starting up and returning to zero, and the "AUTO" symbol is displayed in the timing area, indicating that it enters the automatic mode.
- Put the hand coffee brewing appliance on the scale and weigh it. After the weight is stable, the scale will automatically return to zero.
- Add coffee powder to show the weight. After adding ground coffee, press the $\frac{\text{oz/mg}}{\text{ZERO}}$ key to clear the weight.
- Start water filling after clearing, and the scale will weigh automatically and time automatically. Boil according to the proportion of conventional water and powder.
- After all the items on the scale surface are taken away, the timing is suspended, and the actual weighing weight is locked at the same time. It will be automatically cleared after 5S, and the "AUTO" symbol will be displayed at the same time.
- Automatic shutdown after 180s without weighing operation.

Exit automatic mode

In AUTO mode, double-click $\frac{\text{oz/mg}}{\text{ZERO}}$ to exit AUTO mode

Countdown work

Press $\frac{\text{POWER}}{\text{TIMER}}$ for 3 times to select the countdown function. Press $\frac{\text{oz/mg}}{\text{ZERO}}$ to select time.

Weighing mode

- Place the scale flat on the stable hard table top, press and hold the $\frac{\text{POWER}}{\text{TIMER}}$ key for 2S to start.
- Place the item on the weighing surface, display the weight of the item on the screen. Press the $\frac{\text{oz/mg}}{\text{ZERO}}$ key to peel and return to zero.

Countdown work

- Any modification made without consent will invalidate the warranty.
- This product is powered by lithium battery. It is recommended to charge it in time after the battery power is low.
- Lithium batteries are built-in batteries and should not be disposed of together with domestic garbage. Please refer to local recycling instructions.
- Improper use of batteries and replacement of different types of batteries will result in unusable products.

Specyfikacja

- Wyświetlacz:
- Moc: $\frac{\text{W}}{\text{Watt}}$
- Jednostka domyślna: g
- Automatyczne włączanie/wyłączanie: 180 s
- Ręczne włączanie/wyłączanie: Naciśnij i przytrzymaj $\frac{\text{POWER}}{\text{TIMER}}$ przez 2 s
- Minimalne ważenie: 0.3 g
- Maksymalne ważenie: 3000 g
- Wartość przeciążenia: 3050 g
- Wartości skali: 0.1 g, 0.005 uncji, 0.1 ml
- Zasilanie: 3.7 V (akumulator litowo-jonowy) 400 mA/H
- Dźwięk komunikatu: Po dotknięciu klawisza $\frac{\text{POWER}}{\text{TIMER}}$ i klawisza $\frac{\text{oz/mg}}{\text{ZERO}}$ w stanie rozruchowym brzęczyk emmituje "pikanie".
- Funkcja odrywania: Naciśnij $\frac{\text{oz/mg}}{\text{ZERO}}$, aby przejść do trybu ważenia odrywania

Wskazówki dotyczące ładowania i symboli

- Podłącz kabel ładowający USB do ładowania, dwa segmenty suwaka migają naprzemiennie, a inne suwaki nie są wyświetlane.
- Po zakończeniu pełnego ładowania na ekranie LED wyświetlita się symbol "FULL" (pełne ładowanie 2-5H raz) i rozlega się dźwięk brzęczyka "Beep", ładowanie jest zakończone.
- Wysuwanie i powrotnie suwaka do położenia środkowego, dźwięk brzęczyka i wyświetlacz LED zostanie zresetowany do zera. Wskazówki dotyczące ładowania i symboli
- Monit o przeciążeniu, gdy waża przekroczyc 3050 g
- Monit o niskim napięciu: napięcie poniżej 3.0 V
- Wskazówki dotyczące nie稳定性 ważenia

Konwersja jednostek

- Domyślna jednostka "g" po włączeniu zasilania "g". Konwersja jednostek $\frac{\text{POWER}}{\text{TIMER}}$ przez 2 sekundy w stanie gotowości, a następnie naciśnij i przytrzymaj $\frac{\text{oz/mg}}{\text{ZERO}}$ przez 2 sekundy, aby przejść do cyklu konwersji jednostek "g → oz → ml".

Wyjdź z trybu automatycznego

- W trybie AUTO kliknij dwukrotnie $\frac{\text{oz/mg}}{\text{ZERO}}$, aby wyjść z trybu AUTO
- Naciśnij $\frac{\text{POWER}}{\text{TIMER}}$ 3 razy, aby wybrać funkcję odliczania. Naciśnij $\frac{\text{oz/mg}}{\text{ZERO}}$, aby wybrać czas.

Tryb ważenia

- Polóż wagę płasko na stabilnym, twardym blacie stołu, naciśnij i przytrzymaj $\frac{\text{POWER}}{\text{TIMER}}$ klawisz przez 2 sekundy, aby rozpocząć.
- Umieść przedmiot na powierzchni ważenia, wyświetl wagę przedmiotu na ekranie. Naciśnij $\frac{\text{oz/mg}}{\text{ZERO}}$ klawisz, aby odkleić i powrócić do zera.

Funkcja odliczania

- Wszelkie modyfikacje dokonane bez zgody unieważniają gwarancję.
- Ten produkt jest zasilany baterią litową. Zaleca się naładowanie go w odpowiednim czasie, gdy poziom naładowania baterii jest niski.
- Baterie litowe są wbudowanymi bateriami i nie należy ich wyrzucać razem z odpadami domowymi. Zapoznaj się z lokalnymi instrukcjami dotyczącymi recyklingu.
- Niewłaściwe użytkowanie baterii i wymiana różnych typów baterii spowoduje, że produkty staną się bezużyteczne.

Deklaracja zgodności / Declaration of compliance

Producent: PROLECH Sp. z o.o., Stary Pużnów 58B, 08-400 Garwolin, Polska

Nazwa produktu: Waga kuchenna

Marka: BLOW

Model: KS207

Kod: 44-122#

Producent deklaruje, że wyrob: Waga kuchenna, marka BLOW, kod produktu 44-122#, model: KS207, kod EAN: 5900804145912 jest zgodny z wymaganiami określonymi w dyrektywach 2014/30/EU, 2011/65/EU, (EU) 2015/863, (EU) 2017/2102. Deklaracja zgodności jest dostępna na stronie internetowej: www.prolech.com.pl

The product meets the requirements of the directives: 2014/30/EU, 2011/65/EU, (EU) 2015/863, (EU) 2017/2102. The declaration of conformity is available from the website www.prolech.com.pl

Stary Pużnów, 05.11.2024

Prolech
Sp. z o.o.
Radosław Leszek
Prezes Zarządu



Wyproducedo w CH.R.L dla firmy PROLECH Sp. z o.o., Stary Pużnów 58B, 08-400 Garwolin, Polska
www.blow.pl | www.prolech.com.pl

