

LASER TONER CARTRIDGE INSTRUCTION

Toner Cartridge Instruction

1. Remove the black paper and pull out the seal as shown in pic 1.



2. Remove the protective cover as shown in pic 2.





3. Installation

Step 1: Make sure your printer power is on when you replace a new cartridge.

Step 2: Install the cartridge into the printer and wait for 1-2 minutes.



Step 3: ①When your printer prompts “The indicated cartridges are non-HP cartridges” and the information button  is flashing. Press “OK” to continue.

②When your printer prompts “Memory error on indicated cartridges, Event Code: 10.00.00” and the information button  is flashing, try opening and closing the printer front door. Then an on-screen message “The indicated cartridges are non-HP cartridges” will be displayed and the information button  is flashing. Press “OK” to continue.

