

Scope of application

Cutting branches in orchards, trimming branches in municipal gardens, cutting moso bamboo, chopping firewood at home, necessary for outdoor leisure

Installation instructions

1. Charge the battery, the red light is on when charging, and the green light is on when it is fully charged.
2. Install the chain according to the requirements of the operation diagram.
3. After the installation is complete, first turn on the machine without load and observe the normal operation of the machine.
4. It is not advisable to cut too hard, according to the actual cutting situation, first small and then large.



Brushless Motor


Voltage	guide plate type	sprocket type
21V		
Chain speed	Number of battery packs	
	2	
Length of guide plate	8", 10", 12", 16"	Charging time
		1.5-3 hours

Technical Parameters



Using Manual

Lithium Chain Saw



1. Battery pack

2. Battery level display board

3. Switch

4. Gearbox cover

5. External gear ring

6. Planetary gear

7. Planetary gear carrier
8. Circlip

9. Sprocket

10. Gearbox

11. Guide plate gland

12. Left case

13. Guide plate

14. Bearing
15. Guard plate

16. Output shaft

17. Shaft gear

18. Motor components

19. Right chassis




Figure 1

Figure 1. Install the guide plate.
Note that the direction of the knife edge on the chain is consistent with the direction of the host.




Figure 3

Install the guide plate gland, install the nut and keep it not tightened, use a flat-blade screwdriver to adjust the guide plate tight screw. Keep the chain slightly tight.




Figure 4

Figure 2. Install the chain into the sprocket, and install the guide plate adjustment loose pin into the guide plate hole.




Figure 2




Figure 5

Guard plate installation

Installation Notes